

AVENAR panel 8000 | AVENAR panel 2000 | AVENAR keypad 8000

FPE-8000-SPC | FPE-8000-PPC | FPE-2000-SPC | FPE-2000-PPC |
FPE-8000-FMR




Table of contents

1	Safety and security	7
2	Usage in accordance with regulations	8
3	For your information	9
3.1	Open Source license agreement	9
3.2	Calling up the start menu	9
3.3	Changing language display	9
3.4	Warranty and liability	9
3.5	Copyright	10
4	All functions at a glance	11
5	In overview	13
5.1	Operating elements	13
5.2	Status LEDs	14
5.3	Touch screen	16
5.4	Standby screen	18
5.5	Contact information for support	19
6	Operating principle	20
6.1	Switch on and switch off	20
6.2	Initial setup	21
6.3	Logging on and off	22
6.3.1	Logging on	22
6.3.2	Logging off	22
6.4	Access authorization	23
6.5	Calling up the start menu	23
6.6	Personalized menu	23
6.7	Selecting the menu	23
6.8	Returning to the previous selection	24
6.9	Working with lists	24
6.9.1	Various states of list fields	25
6.9.2	Scrolling through lists	25
6.9.3	Assigning mode	26
6.10	Search Function/Element	26
6.10.1	Search by name	26
6.10.2	Searching by number	27
6.11	Entering numbers and text	27
6.11.1	Changing an entry	28
6.11.2	Deleting all numbers	28
6.12	Changing language display	28
6.12.1	Entering by shortcut	28
6.12.2	Change language by menu	29
6.13	Switching between status bars	29
6.14	Standby	29
6.15	Logical and physical addressing	29
7	Networking via Ethernet	30
7.1	IP settings	30
7.2	Ethernet redundancy	31
7.3	Diagnostics	32
8	AVENAR keypad 8000	33
9	Networked keypads and panels	34

9.1	FSP-5000-RPS configurations	34
9.2	Establishing/closing a remote connection to a panel	34
10	Alarm	36
10.1	Types of alarm	36
10.2	Entry delays	36
10.3	Day and night mode	37
10.4	Alarm message to the panel	38
10.4.1	Optical and acoustic signals	38
10.4.2	Displaying the detector zones in alarm state	38
10.4.3	Sequence of the alarm messages	39
10.4.4	Information about logical zones in the alarm state	39
10.4.5	The newest message	40
10.4.6	Displaying the individual detectors in a logical zone	40
10.4.7	Information about individual detectors	40
10.4.8	Displaying additional information	41
11	Fire alarm	42
11.1	Evacuation	42
11.2	Optical and acoustic signals	43
11.3	Acknowledging a message	43
11.4	Silence internal buzzer	43
11.5	Activate and silence signaling devices	43
11.6	Resetting signaling devices and transmission devices	43
11.7	Alarm verification	44
11.8	Resetting alarm message	45
11.9	Bypassing detectors	46
12	Fault message	47
12.1	Calling up fault indication	47
12.2	Fault message on the panel	47
12.2.1	Acknowledging a message	47
12.2.2	Sequence of the fault messages	48
12.2.3	Information about malfunctioning element groups	48
12.2.4	The newest message	48
12.2.5	Displaying individual elements of an element group	49
12.2.6	Information about individual elements	49
12.2.7	Displaying additional information	49
12.2.8	Signals	50
12.3	Resetting fault message	50
12.4	Blocking an element	51
13	Bypass	52
13.1	Menu overview	52
13.2	Bypassing and un-bypassing elements	52
13.3	Displaying and un-bypassing bypassed element groups	52
13.4	Displaying list of all bypassed elements	53
13.4.1	Using the menu	53
13.4.2	Via the status bar	53
13.5	Bypassing/Un-bypassing buzzer	53
13.6	Bypassing/Un-bypassing the output to fault warning routing equipment	54
13.6.1	Bypassing the output to fault warning routing equipment	54
13.6.2	Un-bypassing the output to fault warning routing equipment	54

14	Block	56
14.1	Menu overview	56
14.2	Blocking and unblocking elements	56
14.3	Displaying list of all blocked elements	56
14.3.1	Using the menu	57
14.3.2	Via the status bar	57
15	Diagnostics	58
15.1	Menu overview	58
15.2	Element details	58
15.3	Modules	59
15.4	Hardware	59
15.4.1	LED test	59
15.4.2	Display test	59
15.4.3	Trace information	60
15.4.4	CAN-Bus	61
15.5	Panel passport	61
15.6	LED Test on modules	61
15.7	Network services	62
15.7.1	Routing table	62
15.7.2	Consistency check	62
15.7.3	Ethernet ports	63
15.7.4	Send ping command	63
15.7.5	Remote Services	63
15.8	Voice alarm systems (VAS)	65
15.8.1	Plena	65
15.8.2	PRAESENSA / PAVIRO / Praesideo	65
16	Maintenance	67
16.1	Menu overview	67
16.2	Change language	67
16.3	Activate Outputs	67
16.4	Activate Transmission Device	68
16.5	Bypassing/Un-bypassing buzzer	68
17	Maintenance – walktest	69
17.1	Walktest groups	69
17.1.1	Adding or deleting elements	69
17.2	Starting and ending walktest	71
17.2.1	Starting the walktest	71
17.2.2	Ending the walktest	72
17.3	Ending walktest for all elements	72
17.4	Displaying tested or untested elements	72
17.5	Assigning tested elements to a walktest group	72
18	Maintenance – history log	73
18.1	Selecting filters	73
18.2	Setting filters	73
18.3	Change Filter	74
18.4	Combining several filters	74
18.5	Status bar functions	74
18.6	Printing out data	74
19	Day and night mode	76

19.1	Switching between day and night mode	76
19.2	Showing details	77
19.3	Changing the time for switching to night mode	77
20	Configuration	79
20.1	Menu overview	79
20.2	Physical node address (PNA/RSN)	79
20.3	Group setting	79
20.3.1	Adding or deleting	79
20.3.2	Change name	81
20.4	Detector sensitivity	81
20.5	Operator	81
20.5.1	Change password	82
20.5.2	Change universal password	82
20.5.3	Set Default Password	82
20.6	Rename elements	83
20.7	Network services	83
20.7.1	Ethernet	83
20.7.2	Change date/time	83
20.7.3	Remote Services	83
20.8	Overview	84
21	Further functions	85
21.1	Menu overview	85
21.2	Change Date / Time	85
21.3	Master password	85
21.3.1	Enter the master password that is valid indefinitely	85
21.3.2	Enter the 24-hour master password	86
21.4	Remote Services	86
21.5	Change password	87
21.6	Performing a fire drill	87
21.7	Alarm counters	88
22	Reset	90
22.1	Menu overview	90
22.2	Resetting elements	90
23	Control / Monitor	91
23.1	Menu overview	91
23.2	Activate doorholder, control element or HVAC	91
23.3	Go to element	91
23.4	Search for function	92
24	Boot menu	93
	Index	94

1 Safety and security

This user manual does not contain general or specialized safety information. It includes only the safety details required for operating the fire panel.

Users must be familiar with all relevant safety procedures and regulations applicable to their location. This includes emergency response actions for alarms and fire incidents.

The user manual is an integral part of the system and must be passed on to the new owner if the system is sold.



Caution!

Risk of system malfunction and data loss

Always use the power button to shut down the panel.

Do not unplug the panel from the power supply while it is in operation.

After the panel has been shut down correctly, you can restart it by pressing the power button again.



Caution!

Risk of system malfunction

Only trained personnel must process event messages on the panel.

Only trained and authorized personnel must perform system walktests and configure detectors.



Caution!

Risk of unauthorized access

The personal access code (user ID and password), must not be disclosed to third parties.



Caution!

Risk of physical damage

Do not use sharp or pointed objects (for example screwdrivers or pens) on the touch screen.

Do not expose the touch screen to direct sunlight.



Caution!

Risk of physical damage

Clean the touch screen and surfaces with a slightly damp soft cloth only.

Do not use any cleaning agents and make sure that no liquid enters the inside of the device.



Caution!

Risk of system malfunction

Calibrate the touch screen at least once a year.

If you do not calibrate the touch screen, the operator may not be able to operate the system.

2 Usage in accordance with regulations

The panel controller is designed for operating the AVENAR panel 8000/2000 fire panel. It can perform the following tasks:

- Displaying and processing various message types such as alarm and trouble messages
- Bypassing, blocking and resetting elements
- Monitoring and controlling of sounders and outputs
- Performing a walktest
- Display diagnostic information about every LSN element
- Configuration of detectors (short texts and detector sensitivity)
- Performing a drill
- Saving, displaying and printing out events
- Switching the system to day or night mode.



Notice!

Terminology

The term **Walktest** (used in the fire panel and documentation) is the same as the EN54-2 standard term **Test condition**.



Notice!

The manual control of evacuation zones and outputs connected to fire protection equipment (e-Matrix) are user features. These features do not have regulatory requirements because they are not part of the EN54-2 standard.

3 For your information

This user manual contains important information and notes on operating the AVENAR panel 8000/2000.

Using the step-by-step directions, you can familiarize yourself with the individual functions:

- In *overview*, page 13 provides an overview of the operating and display elements and the touch screen.
- In *Operating principle*, page 20, you will learn how to navigate through the individual menus and which selection possibilities are available to you.

Each function is described in detail in an individual chapter.

You will find specific topics in the table of contents. If you are already practiced in the handling of menus, you can use the overview of all menus in *All functions at a glance*, page 11.



Notice!

This user manual is applicable for firmware panel version 4.x.

3.1 Open Source license agreement



Notice!

Bosch Sicherheitssysteme GmbH uses Open Source Software. For more information see <https://www.boschsecurity.com/xc/en/oss/>.

3.2 Calling up the start menu

- ▶ Press .

You can use this key to return from any submenu back to the start menu.

3.3 Changing language display

The panel language can be changed quickly with a shortcut:

1. Press  to open the start menu.
2. Press 1 on the alphanumeric keypad.
3. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
A list of the existing languages is displayed.
4. Select the language you require.
All display elements are now shown in the selected language.



Notice!

After a system reboot following a power cut or battery failure, the default language set in the FSP-5000-RPS is displayed again.

3.4 Warranty and liability

Warranty and liability claims for personal and property damage are excluded if these were caused by one or several of the following causes:

- Use of the fire panel contrary to the regulations
- Improper set-up, installation, start-up, operation or maintenance
- Disregarding of the user manual
- Subsequent constructional changes
- Faulty repairs
- Catastrophes, influence of foreign bodies, and force majeure.

Without the permission of Bosch, no changes or additions to or rebuilding of the panel including the panel controller may be undertaken.

Rebuilding requires written permission. In case of non-approved constructional changes, any warranty claims against Bosch are voided.

3.5

Copyright

Bosch Sicherheitssysteme GmbH, Robert-Bosch-Ring 5, 85630 Grasbrunn, Germany retains the complete copyright to the whole documentation. Without the express written permission of Bosch, no part of these documents may be duplicated or transmitted in any form.

Bosch reserves the right to make changes to this manual without prior notice.

4 All functions at a glance

Main menu



Bypass Block	Diagnostics
Maintenance	Configuration
Switch to day mode	Further functions
Control Monitoring	Reset

Bypass/Block

Bypass Block	->	Show blocked/ bypassed devices	Select by number		Bypass buzzer	Printer
		NAC	Transmission device		HVAC	Doorholder
		Detector	Logical zone		Extinguishing system	Annunciator
		Bypass/ Block group	More...	->	Control element	Interface module

Diagnostics

Diagnostics	->	Element details	Modules
		Hardware	Panel passport
		LED test on modules	History log
		Network services	VAS

Maintenance

Maintenance	->	Walktest	Change language
		Activate outputs	Activate transmission device
		History log	Bypass buzzer

Configuration

Configuration	->	Set Physical Node Address (PNA/RSN)	Set groups
		Detector sensitivity	Operator
		Rename elements	Overview
		Network services	About ...

Further functions

Further functions	->	Change date / time	Master password
		Remote Services	Change password
		Drill	Alarm counters

Control / Monitoring

Activate doorholder	Activate HVAC
Activate control element	Search function
Go to element	


Reset

Reset	->	Event type	Scope
		Logical zone	Detector
			This panel

5 In overview

This chapter contains information about the following elements of the panel controller:

- *Operating elements, page 13*
- *Status LEDs, page 14*
- *Touch screen, page 16*
- *Contact information for support, page 19*



- | | | | |
|---|-----------------|----|---|
| 1 | Status LEDs | 6 | Display a list of the networked panels and establish a remote connection with a networked panel |
| 2 | Information bar | 7 | Display and control all alarm zones |
| 3 | Status bar | 8 | Log-in to the panel and call up personalized menu |
| 4 | Open start menu | 9 | Silence internal buzzer |
| 5 | Go back | 10 | Function keys, programmable |
| | | 11 | Display support information |

5.1 Operating elements

Fixed keys

To select a function, touch the appropriate key.

The following functions can be executed with the fixed keys on the bottom of the display:

- | | |
|---|---|
|  | "Home" key. Call up the start menu. |
|  | Return to the previous selection. |
|  | Display a list of the networked panels and establish a remote connection with a networked panel or a remote keypad. |
|  | Display and control all alarm zones. |

	Log in and out: Enter user ID and password or call up personalized menu, if you are already logged in.
	Temporarily silence the internal buzzer.
	"Left arrow" key. Move the cursor one place to the left on the search screen.
	"Right arrow" key. Move the cursor one place to the right on the search screen.
	"Double arrow" key. Switch between status bars if two or more are available. Call up the status bar to scroll rapidly through lists.
	"Enter" key. Confirm an alphanumeric entry. Confirm an entry that is not confirmed by selecting the OK field on the touch screen.

Alphanumeric keypad

Entry of letters, special characters, and numbers.

Function keys


There are three function keys F1, F2 and F3 which are freely programmable with frequently used functions of the panel via the Programming Software. If a function key is active it is marked with a green bar.

5.2


Status LEDs

18 status LEDs show information on the operating status of the fire panel.

	Color*	Meaning
	R	Fire alarm
	R	Evacuation ongoing
	R	Fire alarm transmission activated
	R	Fire protection equipment activated
	Y	Maintenance mode
	Y	Day mode/delays active
	Y	General disabled

	Y	General fault
	Y**	Fire detector fault / disabled
	Y**	Signaling device fault / disabled
	Y**	Alarm transmission device fault / disabled
	Y**	Output to fire protection equipment fault / disabled
	Y	Power fault
	G	Power available
	Y	System/panel fault
	G	System in operation
	R	Programmable LED for a self-defined alarm
	Y**	Programmable LED for a self-defined fault/diasablement
	*Y=yellow, R=red, G=green **blinking: fault, steady: disabled	

The LEDs for the status of devices like detectors , signaling devices , alarm transmission devices  and the outputs to fire protection equipment  always light up in combination with the general fault  or general disabled icon  according to their status. Additionally, in case of a fault the LED of the respective element is blinking while the LED indicating the general fault lights up steadily yellow.

Example:

- 1 Fault indication for a device
- 2 Device disabled
- 3 Device disabled and in fault status

**Notice!**


As neither the panel nor the power supply can have the status “disabled”, the system fault  and the power fault icon  light up steadily in yellow in the status “fault”.

5.3**Touch screen****Caution!**

Risk of physical damage

Do not use sharp or pointed objects (for example screwdrivers or pens) on the touch screen.

Do not expose the touch screen to direct sunlight.



1	Information bar	4	Fixed operation keys
2	Menu field	5	Alphanumeric keypad
3	Status bar	6	Function keys, programmable

Information bar

The information bar displays general information as text or icons.

Icon	Meaning
	No connection established. Only displayed on the panel.
	No connection established. Only displayed on the remote keypad.
	Remote connection established. Operator has restricted use of the remote panel: no control, only monitoring.
	Remote connection established. Operator is in full control of the remote panel.
	Remote connection established. A remote operator is in full control of the panel. The panel is locked for local access.
	Ground fault detected.
	Operator logged in.
Text	Meaning

Icon	Meaning
Panel 4-1	Logical node address
Level 3 logged in	Access level of the operator who is logged in. Possible levels: 2, 3 or 4 Only displayed in the main menu.
Bypass Block\Block\Detector	Menu path of the selected menu For reasons of space it is not always possible to display the complete path.

Menu field

To select a main menu, touch the corresponding menu field on the touch screen. In *All functions at a glance, page 11*, there is an overview of all main menus with their respective submenus.

Status bar

	0 Fire	0 Control	8 Fault	0 Bypass	Status
---	------------------	---------------------	-------------------	--------------------	---------------

This status bar is available on each menu. In addition, other status bars are offered in some menus; see also *Switching between status bars, page 29*:

The leading number specifies the number of elements in the respective state:

Fire Number of groups that have triggered a fire alarm

Control Elements that are activated

Fault Elements that have reported a fault

Bypass Disabled elements

In addition it is possible to display an overview of the type and nature of all message types received by the panel:

Status Display of a list of the various message and status types and the number of elements in the respective state

To display the individual elements, touch the relevant field with your finger.

The **Control** and **Fault** status fields are identified by the letters "B" and/or "C":

- "B" means that controllers for type B fire protection equipment (G-B) are affected (e.g. control elements without acknowledgement).
- "C" means that controllers for type C fire protection equipment (G-C) are affected (e.g. extinguishing systems).

5.4 Standby screen

When the touchscreen is not operated, its backlight switches off after 5 minutes.



Notice!

In case of an active alarm or fault message, the backlight switches off after 60 minutes. The display switches back to this message from any other element of the menu after 30 seconds.

If the screen is black, touch it gently to display the standby screen. The following information is displayed on the standby screen:

- Date
- Time
-  Night mode

or

-  Day mode

or

-  Night/day combination

Depending on the configuration, additional information may be displayed.

In a networked fire detection system, further icons can be displayed in the standby display depending on the network setting.

5.5 Contact information for support

To display the contact information of the company that provides the support, press the Bosch logo in the upper right corner of the user interface.

Following contact information is shown:

- **Company name**
- **Contact name**
- **Phone**
- **Address**
- **Post code**
- **E-mail**



Notice!

The contact information for support is only shown, when the information has been entered in the support information dialog in FSP-5000-RPS.

Besides the contact information, following information is shown:


- **Date system installed:** The date, the time and the time zone of the last configuration download.
- **Firmware version:** Firmware version that is currently running on the controller hardware.
- **Hardware version:** With the hardware version you can identify which firmware version can run on the controller. For further information, see chapter *Panel controller firmware* in the system manual.

6 Operating principle

6.1 Switch on and switch off

Power button

The fire panel must be switched on and off with a power button which is located at the right side of the panel. Also a reboot of the panel is done via the power button.



Caution!

Risk of system malfunction and data loss

Always use the power button to shut down the panel.

Do not unplug the panel from the power supply while it is in operation.

After the panel has been shut down correctly, you can restart it by pressing the power button again.



Power button functions

1. Start the panel: Press the power button one time shortly.
2. Shut down the panel: Press the power button one time shortly when the panel is running.
 - The panel plays a confirmation sound when the shutdown sequence starts.
 - The shutdown is complete when the “general fault”  and the “system/panel fault”  LEDs light up.
 - Wait until the shutdown is complete.
 - Then interrupt the power supply.
 - If the panel is shut down but still has power, a warning tone sounds after 10 seconds.
3. Reboot after software failure: Press and hold the power button for 8 seconds.

Caution!

Risk of improper use of the reboot procedure

Only press the power button for 8 seconds in case of:

- a) The system does not respond anymore.
- b) You are instructed to do so because the panel has entered the safe state.



Safe state



Notice!

To avoid the panel running into a safe state, do not reboot the panel twice within 100 seconds.

If the panel reboots twice within 100 seconds (either because of a system error or intentionally for example during the initial set-up) it runs into a safe state which can be ended by a manual restart only. A warning tone sounds and a message appears on the screen. In this case, please follow the instructions on the display.

6.2

Initial setup

When you start the panel for the first time, you must perform the following steps:

Calibrate touch screen

When initially starting the panel, first of all you must calibrate the touch screen:

1. Switch on the panel by applying power or pressing the power button. The touchscreen calibration procedure will start automatically if required.
2. Perform the calibration by following the instructions on the screen.

The boot process will automatically continue after the calibration was completed.

Set time and date

Touch the field you require and enter the correct value. For details see *Change Date / Time*, page 85

Set physical node address (PNA/RSN)

You must set the physical node address (PNA/RSN) when switching on the panel for the first time.



Notice!

There are no mechanical rotary switches.

The physical node address must be identical with the number configured in the programming software. After a change of the physical node address, a reboot of the panel is required.

To change the physical node address enter a number between 1 and 64. Choose **OK and reboot** to make the change effective.

Use Ethernet settings

Check **Use Ethernet settings** if the panel is used within an Ethernet network.



Caution!

Risk of network fault

If you check **Use Ethernet settings** you must set the panel IP address using **Configure Ethernet**.

Use RSTP

Check **Use RSTP** to activate Ethernet redundancy. For details see *Ethernet redundancy*, page 31.

Configure Ethernet

Check **Configure Ethernet** to use the standard IP address of the panel.

Reboot

After having made all the necessary settings, reboot the panel by pressing **Reboot**.

6.3 Logging on and off

To gain access to access levels 2 to 4, it is necessary to log on. The prerequisite is that you have access authorization.

Notice!

To log on, you need a user ID and password. Depending on your access authorization, you can use only particular functions.

In the following cases, you will be asked to enter a password:

You are not logged on and want to select a function for which a password is required.

You are already logged on but a higher access authorization is required for the function you have selected.

6.3.1 Logging on

To log on to the panel controller:

Press the login key .

The login window is displayed:

1. Enter your user ID in the first field.
Refer to *Entering numbers and text, page 27* for information on how to enter numbers.
2. Enter your password in the second field.

**Notice!**

The default password is: 000000. For security reasons please change this password, see *Change password, page 87*.

3. Select **OK** to confirm the entries or **Cancel** to cancel the operation.
Refer to *Change password, page 87* for information on how to set up your own password.

The standby display is shown.

As long as an operator is logged on, the key icon will be displayed on the information bar.

In addition, the user ID of the user who has logged on is displayed on the start page on the information bar.

**Notice!**

In the FSP-5000-RPS programming software, a time span can be specified after which an operator who is logged on to the panel controller is logged off.

6.3.2 Logging off

1. To log off from the panel controller, press .

An input window with the request **Log off?** is displayed:

2. Select **Yes** to confirm the request or **No** to cancel the operation.

6.4 Access authorization



Notice!

Depending on your access authorization, you can only use certain functions of the panel controller.

If you select a function for which a particular access authorization is required and no user with the appropriate authorization is logged on, you will be asked to enter your user ID and password.

Access authorizations are assigned for access levels two to four. Only a few functions can be used on access level one, while all functions can be used on access level four.

To check the access authorization of the person who is logged in, press  after logging in:

The relevant access authorization is displayed.

6.5 Calling up the start menu

Press the "home" key to return to the start menu from any submenu.



Notice!

The display changes from each menu element to the standby display if no entries are made after 5 minutes, in case of an alarm or a fault message after 60 minutes, see also *Standby screen, page 18*.

If the screen is black, touch it gently to display the standby screen.

6.6 Personalized menu

Via the FSP-5000-RPS programming software you can configure your personalized start menu which displays up to eight functions you need most often directly when you log in to the panel.

To retrieve the personalized menu log on to the panel: Press the login key and enter your user ID and password.



To change back from the personalized menu to the common main menu press the "home" key.



To change back to the personalized menu from any other screen, press the login key.



6.7 Selecting the menu

In order to select a menu in the main menu, touch the field you require with your finger: The submenus are displayed.


To select a submenu, gently touch the required field.

6.8 Returning to the previous selection

To return to the previous selection, press the "Back" key:



6.9 Working with lists



1	List	4	Scroll up / scroll down
2	List field	5	Function fields
3	Search mask		

In many menus, elements are displayed in lists. The elements are sorted either by description or address. Up to three different sorting criteria can be offered:

- **By description:** sorted by description in alphabetical order; address allocation also given.
- **By number:** sorted in ascending order by number (logical or physical address); description also given.
- **By number (no description shown):** by number (logical or physical address) in ascending order; the numbers are displayed in number blocks and the description is not given. This list is only offered when detectors and logical zones are being selected.

Example:

To display a list of all existing detectors sorted by description in the **Bypass** submenu, select the following in the start menu:

1. **Bypass Block**
2. **Bypass**
3. **Detector**

Three sorting criteria are offered for selection:

- **By description**

- **By number**
- **By number (no description shown)**
- ▶ **Select By description.**
A list of all detectors is displayed, sorted in alphabetical order.

6.9.1 Various states of list fields

Various states can be assigned to an element or an element group, depicted by a list field. The following table provides information about the possible states:

List field	State of list field	Meaning
	normal	Element in normal state
	marked	Selected element
	Mode assigned	The element was assigned the bypassed mode; see <i>Assigning mode, page 26</i> .
	Mode assigned and marked	The selected element has already been assigned a particular mode. It is selected in order to reset it to the original mode; a bypassed element is unbypassed, for example.
	In reset mode	The resetting of the element is not yet complete.

"Bypass" menu

In the **Bypass** menu, list fields can display additional information; see the following table:

List field	In the Bypass menu
	The bypassed element is in alarm mode. If it is un-bypassed, it triggers a fire alarm. To display more information, press the right-hand field.
	Display a bypass group that consists of several elements. In order to display a list of all elements of the bypass group, press the right-hand field.

6.9.2 Scrolling through lists

On the display, only a limited number of list fields can be displayed.

Scrolling:

To scroll back through the list, select:

To scroll forward through the list, select:

The arrows will only be displayed if scrolling is possible.


Rapid scrolling:



To scroll quickly through a list, select on the alphanumeric keypad or on the status bar of the display.

Jumping to specific positions:

To jump to a specific position in the list, gently touch the horizontal line of the scrollbar:



To jump to the beginning of the list, select: 

To jump to the end of the list, select: 

6.9.3**Assigning mode**

A mode like Bypassed, Walktest etc. can be assigned to selected elements.

To assign a mode to selected elements, select the corresponding function field.

In the following example, a detector is assigned bypassed mode in the **Bypass Block** menu:

1. Select the list fields you require from the list.

The list fields are marked.

2. Select the **Bypass** function field.

The detectors are bypassed. The list fields are highlighted in a dark color.

The sand glass icon indicates an entry that is still being processed by the system.

**Notice!**

In the **Bypass** submenu, the function fields have an additional selection option; see Displaying and un-bypassing bypassed element groups.

6.10**Search Function/Element**

In lists, a particular element can be searched for and displayed using the search screen. The following search criteria are offered:

- **By description:** The element is searched for in the list by its description.
- **By number:** The element is searched for in the list by its number. In some menus, the **By number (no description shown)** search function is offered.

In the **Search function / element** main menu, it is possible to search for all elements connected to the system and all functions offered in the panel controller, as well as device descriptions, regardless of which menu they appear in; see Search Function/Element.

6.10.1**Search by name**

To search in the **By description** list for a particular element, enter the name of the element in the search screen.

Entering numbers and text explains how to enter text.

Enter the initial letter and, if necessary, other letters.

The name is automatically completed once it has been uniquely recognized. The list field of the element you are searching for is displayed at the beginning of the list.

**Notice!**

The more accurately the description of an element is entered in the FSP-5000-RPS programming software, the easier the search by name will be.

6.10.2 Searching by number

To search in the **By number** and **By number (no description shown)** list for a particular element:

1. Enter the first digit, for example 1.
2. Press the "Enter" key to confirm the entry.

If the entry of another number is possible, a second search window is displayed.



Notice!

If you are not offered another field, there is no element with the addressing you have searched for.



3. Enter the next digit and confirm your entry with the "Enter" key.
4. If necessary, enter further digits until the number is shown in full. You must confirm each entry with the "Enter" key.

The list field of the element you are searching for is then displayed at the beginning of the list.

6.11 Entering numbers and text

Press the corresponding key on the alphanumeric keypad until the required letter or number is displayed.

Key	Character
	.,_0
	← 1
	ABCabc2
	DEFdef3
	GHIghi4
	JKLjkl5
	MNOmno6
	PQRSpqrs7
	TUVtuv8

Key	Character
	WXYZwxyz9
	*
	#

**Notice!**

You can enter only numbers in the search screen for the **By number, By number (no description shown)** lists, and the user login.

You can enter both letters and numbers in the search screen for the **By description** list.

Quick entry:

In order to enter text quickly, press the "Enter" key after entering each letter.

This takes the cursor to the next free character and you can continue with entering the next letter.

6.11.1**Changing an entry**

1. In order to change a number, press the "left arrow" or "right arrow" keys until the cursor marks the number in the search screen that is to be replaced.
2. To overwrite the marked number, press the key with the required number until the number you require is displayed in the search screen.

6.11.2**Deleting all numbers**

1. In order to delete all numbers in the search screen, press the "left arrow" key until the cursor marks the first number.
2. Enter a new number using the number pad.
All numbers up to the digit entered are deleted.
3. If you wish to, continue entering the numbers.

6.12**Changing language display**

There are two ways to select another language display:

- By entering a shortcut
- Via a menu selection

6.12.1**Entering by shortcut**

The panel language can be changed quickly with a shortcut:

1. Press  to open the start menu.
2. Press 1 on the alphanumeric keypad.
3. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
A list of the existing languages is displayed.
4. Select the language you require.
All display elements are now shown in the selected language.



Notice!

After a system reboot following a power cut or battery failure, the default language set in the FSP-5000-RPS is displayed again.

6.12.2 Change language by menu

1. In the start menu, select **Maintenance**
2. **Change language**
A list of the languages which can be selected is displayed.
3. Select the language you require.
All display elements are now shown in the selected language.

6.13 Switching between status bars

The status bar offers further functions, display and selection options.

If the "double arrow" symbol is displayed in the status bar, it is possible to switch to the

status bar of the start menu. To do this, press the "double arrow" key  on the alphanumeric keypad.

6.14 Standby

When the touchscreen is not operated, its backlight switches off after 5 minutes.



Notice!

In case of an active alarm or fault message, the backlight switches off after 60 minutes. The display switches back to this message from any other element of the menu after 30 seconds.

If the screen is black, touch it gently to display the standby screen.

6.15 Logical and physical addressing

When addressing elements, there is a distinction between logical and physical addressing:

Physical			
Elements	Modules	Loop	Element
Numbers	5	1	4
Logical			
Elements		Zone	Element
Numbers		3	4

Examples:

Element with physical addressing: 5.1 - 4

Element with logical addressing: 3 - 4

7 Networking via Ethernet

This chapter contains notes on networking via Ethernet. The networking of several panels via Ethernet is only possible for the AVENAR panel 8000 and the premium version of AVENAR panel 2000. The AVENAR panel 2000 standard version can be networked with up to three remote keypads (FPE-8000-FMR) via Ethernet.

After installing the panels, various network settings must be made at the panel controller in order to set up the network.



Notice!

Default settings that are to be used for default configurations are provided both for IP settings and for redundancy settings for redundancy with the Rapid Spanning Tree Protocol (RSTP). Changes may only be made by trained specialist personnel. Competent knowledge of networking and protocols is essential! Permission level 4 is required for changes to the network settings of a previously configured panel.

7.1 IP settings

To modify values for Ethernet settings or to configure these for the first time, select in the start menu:

1. **Configuration**
2. **Network services**
3. **Ethernet**. The **Configure Ethernet** screen is displayed.
4. Activate the checkbox **Use Ethernet settings**.
5. Select **IP settings**. The values for IP address, network screen, default gateway, multicast address and port number are indicated. When you commission the panel controller for the first time, all values are set to "0".
6. Select **Default settings** to overwrite these values with the default settings saved in the panel controller (recommended!). The IP address in this case corresponds to the stored default IP address, the last number of which matches the physical node address (PNA/RSN) that was set during installation at the panel controller.
7. If the planned configuration requires a change to the default values:
Touch the field containing the value to be changed. Use the arrow keys on the operating panel to select the desired numbers and modify the values using the number keys on the alphanumeric keypad.
Or:
Touch the **Change** field. Touch the field containing the number block to be changed. Use the arrow keys on the operating panel to select the desired numbers and modify the values using the number keys on the alphanumeric keypad.
Touch **OK** to apply the changes or **Cancel** to discard the changes. You are returned to the initial **Configuration IP** screen.
8. Select **OK** to apply the changes to the IP settings or **Cancel** to discard the changes. You are returned to the **Configure Ethernet** screen.
9. Select **OK** to confirm application of the Ethernet settings (**Use Ethernet settings**) or **Cancel** to exit the screen without activating the Ethernet settings.



Notice!

Changes to Ethernet settings take effect after restarting the panel.

7.2 Ethernet redundancy

Depending on the topology of the network, it may be necessary to select a redundancy protocol. The default setting for the redundancy mode is **Off**.

To specify a redundancy mode, go to the start menu and select:

1. **Configuration**
2. **Network services**
3. **Ethernet**. The **Configure Ethernet** screen is displayed.
4. Activate the checkbox **Use Ethernet settings**.
5. Select **Ethernet redundancy**
6. Select the redundancy type from: **RSTP** or **Off**.
7. Select **OK** to apply the change to the redundancy mode or **Cancel** to discard the changes. You are returned to the **Configure Ethernet** screen.
8. Select **OK** to confirm application of the Ethernet settings (**Use Ethernet settings**) or **Cancel** to exit the screen without activating the Ethernet settings.



Notice!

The change to the redundancy mode takes effect after restarting the panel.

RSTP settings

In the case of redundancy via RSTP, additional settings need to be made.



Notice!

Default settings that are to be used for default configurations are provided for the RSTP parameters. Changes may only be made by trained specialist personnel. Competent knowledge of networking and protocols is essential! Permission level 4 is required for changes to the RSTP parameters of a previously configured panel.

To modify the parameters for redundancy via RSTP or to configure these for the first time:

1. Select **RSTP** as the redundancy type.
 2. Select **Set parameters ...**. The values for bridge priority, hello time, maximum age and forward delay are indicated. When you commission the panel controller for the first time, all values are set to "0".
 3. Select **Default settings** to overwrite these values with the default settings saved in the panel controller (recommended!).
 4. If the planned configuration requires a change to the default values:
Touch the field containing the value to be changed. Use the arrow keys on the operating panel to select the desired numbers and modify the values using the number keys on the alphanumeric keypad. If the values are outside of the defined minimum or maximum values, the changes are not applied or a warning is displayed. If the values are inconsistent, a formula appears indicating the corresponding dependencies of the values as they relate to one another.
 5. Select **OK** to apply the changes to the RSTP parameters or **Cancel** to discard the changes.
-



Notice!

Changes to RSTP parameters take effect after restarting the panel.

7.3 Diagnostics

Diagnostics information and help materials for pinpointing problems in a network can be found under menu item **Diagnostics - Network services**. Information is provided on the following topics:

- **Routing table**
Information concerning the accessibility of all nodes within the system network via the respective interface.
 - **Ethernet ports**
Information concerning different parameters and the status of the two Ethernet interfaces available at the panel controller.
 - **Send ping command**
Sending of a ping command to a specific IP address to check the availability of other nodes in the network.
 - **Consistency check**
The check performed determines whether the Ethernet configuration from FSP-5000-RPS corresponds to the configuration entered at the panel controller. In the event of discrepancies, a fault message is displayed.
 - **Ethernet redundancy**
Information concerning redundancy. The RSTP parameters of the RSTP panel and those of the root bridge are displayed.
 - **Remote Services**
Information concerning the features and the status of the Remote Services.
- Further information can be found in *Network services*, page 62.

8 AVENAR keypad 8000

The AVENAR keypad 8000 is a user-friendly interface that adapts to various situations. The design of the graphical user interface is identical to the fire panels.

The keypad can be used in the following mutually exclusive applications:

- Remote keypad
 - Displaying messages
 - Remote connection to a panel
- Panel controller redundancy

Displaying messages

The remote keypad is by default programmed to display messages, even if no operator is logged into the keypad. In this case, the operation of all functions with permission level 1 are possible.



Notice!

In FSP-5000-RPS, you can define that when no operator is logged in, only the standby screen is displayed. In this case, no LEDs are activated and no messages are displayed. In order to activate the LEDs and display messages, an operator with permission level >1 must log in.

Remote connection to a panel

The remote keypad allows decentralized operation of the system by establishing remote connections to the panels.

If the keypad is not connected to a panel, the following icon is displayed on the standby display and in the status bar:

For more information about remote connection, see chapter *Networked keypads and panels*, page 34.

Panel controller redundancy

In combination with an AVENAR panel 8000, the keypad can be used as a redundant panel, for example, when the main panel controller breaks down. In this case, the keypad cannot be used as a remote keypad.

9 Networked keypads and panels

The keypads and the panels of the AVENAR series can be connected to another physical panel through the Ethernet and the CAN bus interfaces.

There are two types of a remote connection:

– Full control

As an operator of a remote keypad or a remote panel, you have full control of the physical panel. You can perform all functions.

The standby display and the status bar of the remote keypad or the remote panel indicate

full control by this icon: 



Notice!

When a connection with full control to the physical panel is established, the physical panel is locked for local access. The standby display and the status bar of the physical panel

indicate locked access by this icon: 

– Restricted use

As an operator of a remote keypad or a remote panel, you have restricted use of the physical panel. You can only reset elements and read the history log.

The standby display and the status bar of the remote keypad or the remote panel indicate

restricted use by this icon: 



Notice!

When another operator is already locally logged into the physical panel, a connection with restricted use is established to the remote keypad or the remote panel. The local operator must log out first before a connection with full control can be established.

9.1 FSP-5000-RPS configurations

In FSP-5000-RPS, the configuration of following settings will have an impact on the networked keypads and panels:

- You can define two types of scope:
 - Network: The conditions and the messages of all panels within the network are displayed on the remote keypad or the remote panel.
 - Group: Only the conditions and the messages of the panels in the same group network are displayed on the remote keypad or the remote panel.
- You can define a time after which a logged-in operator is logged out from the panel. The default timeout is 60 minutes.
- In the configuration of the AVENAR keypad 8000 node, you can enter the address of the physical panel to which a remote connection is automatically established.

9.2 Establishing/closing a remote connection to a panel

Establishing a remote connection to a panel

1. On your keypad or panel, press . The display shows a list of available panels and keypads.
 2. Select a panel and press **OK**.
 3. Press again **OK**.
- ⇒ The remote connection to the physical panel is established.

Closing a remote connection to a panel

1. On your remote keypad or remote panel, press .
 2. To confirm, press **Yes**.
- ⇒ The remote connection to the physical panel is closed.

10 Alarm



Notice!

Information on how to handle a fire alarm can be found in *Fire alarm*, page 42.

This chapter contains information about the following points:

- *Types of alarm*, page 36
- *Entry delays*, page 36
- *Day and night mode*, page 37
- *Alarm message to the panel*, page 38

Refer to the Fire alarm chapter for the following topics:

- *Acknowledging a message*, page 43
- *Silence internal buzzer*, page 43
- *Activate and silence signaling devices*, page 43
- *Resetting signaling devices and transmission devices*, page 43
- *Triggering fire verification*
- *Resetting alarm message*, page 45
- *Bypassing detectors*, page 46



Notice!

Depending on the configuration, the manner in which alarm displays are shown and handled in this guide may differ from the guide on the system.

10.1 Types of alarm

On the panel controller, a distinction is made between the following types of alarm:

- **Fire**
- **Heat**
- **Smoke**
- **Water**
- **Supervisory**

Depending on the configuration, external transmission devices (e.g. fire department), notification appliances (e.g. sirens and/or strobes) and fire protection systems (e.g. sprinkler systems, fire doors) are activated.



Notice!

If an alarm delay is set for the detector triggering the alarm, the alarm signal is not transmitted immediately and the message can be checked; see *Entry delays*.

10.2 Entry delays

To prevent false alarms, it is possible to delay the transmission of the first alarm signal. The transmission device to the fire department is not activated immediately in this case. During the delay, the message can be checked to ensure it is correct.

The FSP-5000-RPS programming software can be used to program various strategies for avoiding false alarms. These strategies are principally used in fire detectors but can also be assigned to any other detector, depending on how it is configured.

The alarm delays that can be shown in the panel controller display are explained below.

Alarm verification

When the alarm message is acknowledged on the panel controller, a time to investigate is started. During this time, the message in the place where the detector generating the alarm is located must be checked to ensure it is correct. The duration of the verification time can be freely configured for every detector. See also Fire alarm and Triggering fire verification. If it is determined during the test that the alarm is genuine, an alarm can either be triggered manually or by activating a manual call point. The transmission device to the fire department is activated.

Depending on the configuration, a pre-alarm is displayed for the following alarm delays:

- Intermediate alarm storage
If a detector with intermediate alarm storage triggers an alarm, this is displayed as a pre-alarm on the system. The transmission device to the fire department is not activated. The detector generating the alarm is reset after the first signal. The pre-alarm becomes an alarm if the same detector triggers an alarm signal again within a set time. The time until a main alarm is triggered is shown on the display. The transmission devices and signaling devices are activated.
- Dual-detector dependency
If a detector triggers an initial alarm within a dual-detector dependency, then this is displayed on the system as a pre-alarm. The transmission device to the fire department is not activated. The detector generating the alarm is reset after the first signal. The pre-alarm becomes the main alarm if a second detector in the same logical zone triggers an alarm. The transmission devices and notification appliances are activated.
- Dual-zone dependency
If a detector triggers an initial alarm within a dual-zone dependency, then this is displayed on the system as a pre-alarm. The transmission device to the fire department is not activated. The detector generating the alarm is reset after the first signal. The pre-alarm becomes the main alarm if a second detector in a different logical zone triggers an alarm. The transmission devices and signaling devices are activated.

10.3 Day and night mode



Notice!

Depending on the configuration, the manner in which the difference between day and night mode is displayed may differ from that on the system.

Depending on the configuration, an incoming alarm is handled differently in day and night mode:

Night mode



Night mode has the highest security level. Depending on the configuration, the alarm message is generally transmitted to the fire department without a delay.

Signaling devices (e.g. sirens) and transmission devices to the fire department or fire protection systems are activated.

If the transmission device to the fire department is activated, the  LED icon lights up red.

Depending on the configuration, a detector in night mode triggers a pre-alarm if intermediate alarm storage is used as an alarm delay for this detector.

Day mode**Notice!**

Depending on the security level in question, not all detectors can be switched to day mode.

Depending on the configuration, a distinction is made between the following possible alarm delays in day mode:

– **Alarm verification**– **Pre-alarm**

A pre-alarm is displayed for the following alarm delays:

- Intermediate alarm storage
- Dual-detector dependency
- Dual-zone dependency

For a detailed description of the various alarm delays, see Entry delays.

– **Internal alarm**

An alarm that is reported to the panel in day mode. No transmission devices to the fire department are activated.

10.4 Alarm message to the panel

The following description has been written on the basis of a sample fire alarm message.

10.4.1 Optical and acoustic signals



- The LED alarm icon  lights up red.
- An internal buzzer sounds; see also *Silence internal buzzer, page 43*.
- Depending on the configuration, sounders and/or visual notification appliances (e.g. sirens, strobes) are activated.

If the transmission device to the fire department is activated, the  LED icon lights up red.

10.4.2 Displaying the detector zones in alarm state

The number of messages in question is displayed on the status bar.

**Notice!**

First of all, the logical zones in which one or more detectors have triggered an alarm are listed. To display the individual detectors, select the logical zone you require. See also *Displaying the individual detectors in a logical zone, page 40*.

The individual messages are shown in the display:

- List fields with white background: unacknowledged alarm messages
- List fields without distinction: acknowledged alarm messages

Logical Zones



Notice!

A maximum of four alarm messages can be displayed on the display simultaneously. Only fields that can be operated are displayed (e.g. **Acknowledge** and **Reset**).

If more than four alarm messages have been received, scroll through the list in order to display the next messages.



Notice!

The latest message is always displayed at the end of the list.

Display during an alarm

The buttons located beneath the alarm message on the display can be used to initiate the corresponding actions:

Acknowledge	Signals off	Signals on	Reset
--------------------	--------------------	-------------------	--------------

- **Acknowledge:** Touch this button to acknowledge all of the alarm messages shown on the display; see also Acknowledging a message.
- **Signals off:** Touch this button to switch off activated external notification appliances; see also Switching external signaling devices on and off.
- **Signals on:** Touch this button to switch on deactivated external notification appliances; see also Switching external signaling devices on and off.
- **Reset:** Touch this button to reset all of the alarm messages shown on the display; see also Resetting alarm message.

10.4.3

Sequence of the alarm messages

The messages are displayed in chronological order.

- The newest alarm message of a logical zone is always displayed at the end of the list.
- The first and oldest alarm message of a logical zone is displayed at the beginning of the list. The next three messages are displayed as you scroll through the list.



Notice!

30 seconds after the last entry (e.g. after scrolling through the list), the first and oldest alarm is displayed at the beginning of the list again.

10.4.4

Information about logical zones in the alarm state

The alarm message contains information about:

- The element category
- The message type
- The address of the detector group
- The number of detectors that have triggered an alarm in the respective logical zone
- The message number
- Depending on the configuration, additional information such as the installation location

Example:

Fire		Zone	00005	
------	--	------	-------	--

#001	Office 1			(6)
------	----------	--	--	-----

Message type

The message type **Fire** is reported.

Depending on the configuration, the message type may be defined more specifically, e.g. Fire PAS for a fire alarm with alarm verification.

Address of logical zone

00005: the fifth logical zone triggered the first fire alarm.

Number of detectors

(6): In the fifth logical zone (00005), six detectors (6) triggered a fire alarm.

For logical zones that only consist of one element, no number of detectors is displayed.

**Notice!**

Depending on the configuration of the system, either the logical or physical address of the detector is displayed.

Message number

The alarm messages are numbered chronologically.

The message number in the second line indicates the sequence in which the alarm messages arrived.

#001: The first alarm message that came in.

Depending on the configuration, additional information is displayed in the second line, such as the installation location of the logical zone.

10.4.5**The newest message**

The latest message is always displayed at the end of the list.

The message number (e.g. #008) of the latest message indicates the total number of logical zones in which one or more detectors have triggered an alarm.

10.4.6**Displaying the individual detectors in a logical zone**

To display the individual detectors in a logical zone, select the logical zone you require.

The alarm messages for the individual detectors are listed.

10.4.7**Information about individual detectors**

Each alarm message contains information about:

- The element category
- The message type
- The detector address
- The message number
- Depending on the configuration, additional information such as the installation location

Example:

Fire		Detectors	00005 - 004
#002	Office 1		

Message type

Refer to Information about logical zones in the alarm state for information on the type of message.

Message address

In this example, the following detector has triggered a fire alarm:

0005 - 004: the fourth detector (004) in the fifth logical zone (00005).

If the detector number, in this case (004), is not displayed, this is the alarm message for the logical zone.



Notice!

Depending on the configuration of the system, either the logical or physical address of the detector is displayed.

Message number

For information on the message number (#002), see Information about logical zones in the alarm state.

Depending on the configuration, additional information is displayed in the second line, such as the installation location of the detector or the detector type.

To display more information about an alarm message, see Displaying additional information.

10.4.8

Displaying additional information



Notice!

By way of example, an action text can be entered for every detector type in the FSP-5000-RPS programming software.

To display further information about the individual detectors, select the alarm message you require.

The following information is displayed:

- Element category
- Message type
- Date and time of the message
- Physical and logical addressing of the detector
- Only for LSN detectors: specification of the detector type
- Action text (depending on the configuration)

11 Fire alarm



Notice!

Detailed information about types of alarms, alarm delays and the panel controller display can be found in *Alarm, page 36*.

This chapter contains information about the following points:

- *Optical and acoustic signals, page 43*
- *Acknowledging a message, page 43*
- *Silence internal buzzer, page 43*
- *Activate and silence signaling devices, page 43*
- *Resetting signaling devices and transmission devices, page 43*
- *Alarm verification, page 44*
- *Resetting alarm message, page 45*
- *Bypassing detectors, page 46*

Signaling fire alarms

A fire alarm is signaled optically and acoustically on the panel through:

- Displaying the logical zones on the display
- Lighting up the "Alarm" LED icon 
- An internal buzzer sounds on the system.



Notice!

Alarm messages have the highest priority compared with all other message types. If a fire alarm is reported, the system switches automatically to alarm indication.

11.1 Evacuation

You can manually control all available evacuation zones.

Press the evacuation button  to open the list with all available evacuation zones. To search for a specific zone, enter the number of a group of notification appliances and press .



Notice!

The individual control of each group is only possible for panel controllers with a premium license.

Select the required group to start or stop the evacuation of this zone immediately. Use  and  to scroll through the list. The group entries change their background color according to their current state.

Select **All On** to control all evacuation groups or **All Off** to stop the activation of all groups at a time.

The background colors of the groups have the following meaning:

- Red: Groups which are actively being controlled in case of an alarm
- Fuchsia: Groups which are actively being controlled without a real alarm, e.g. in case of a fire drill

- Green: Groups which are not active
- Yellow: Groups in fault or disabled, no control is possible.

11.2 Optical and acoustic signals

- The alarm LED  and the evacuation LED  light up red
- An internal buzzer sounds; see also *Silence internal buzzer*, page 43.
- Depending on the configuration, sounders and/or visual notification appliances (e.g. sirens, strobes) are activated.

If the transmission device to the fire department is activated, the  LED icon lights up red:

11.3 Acknowledging a message

There are two ways to acknowledge messages:

- Select **Acknowledge**. Only those alarm messages which are visible in the display are acknowledged.
- Select a message and then press **Acknowledge**. Only the selected message is acknowledged.



Notice!

If **Go to Acknowledge** is displayed, select this field in order to display the messages that have not yet been acknowledged.

11.4 Silence internal buzzer

Press the following key to temporarily silence the internal buzzer:



The internal signal tone is silenced.

11.5 Activate and silence signaling devices

Sounders and optical signaling devices which have been activated can be switched off.

- ▶ Select **Signals off**.
The sounder and/or optical signaling device is switched off.



Notice!

On the next alarm message, all signaling devices that have been switched off are switched back on automatically.

- ▶ To switch the notification appliance back on, select **Signals on**.
The signaling devices are switched on again.

11.6 Resetting signaling devices and transmission devices

- ▶ To reset control or transmission devices, select **Control** in the status bar

**Notice!**

The display automatically changes back to alarm indication after 30 seconds. To return to the alarm indication before 30 seconds have elapsed, select **Fire**.

- ▶ Select the signaling device.
Only the activated signaling devices are displayed.
- 1. Select one or more list fields.
The list field is marked.
- 2. Select **Reset**.

The control units are reset to the initial state.

In the **Control** field on the status bar, the number of control elements is reduced by the number of reset elements.

To reset transmission devices, carry out the same steps, but select **Transmission device** in step 1.

11.7

Alarm verification

The transmission of the alarm can be delayed in day mode.

The alarm message must be checked by the operator to determine if the alarm is genuine. In case of an alarm, the internal buzzer sounds. The signaling devices (e.g. sirens) and transmission device to the fire department are not activated.

During the alarm verification, the system displays following countdown timers that count down to zero:

- **Time to acknowledge**
- **Time to investigate**
- **Reset possible in**

Procedure

1. To start an alarm verification, select **Acknowledge** within the displayed time to acknowledge the alarm.
2. The system displays the time to investigate. During this time, check the place where the detector is generating the alarm.
3. If you determine during the verification that the alarm is genuine, either trigger an alarm manually by selecting **Manual alarm** on the panel or by activating a manual call point.
4. The evacuation is starting and the transmission device to the fire department is activated.
5. If you recognize a false alarm, select **Reset** on your panel.

Notes

- If you do not confirm or verify the alarm within the specified time, the system will automatically activate the signaling devices and send the alarm to the fire department.
- If the system triggers a second alarm during the verification process, the verification is immediately interrupted. The system will then automatically activate the signaling devices and send the alarm to the fire department.
- If a second alarm occurs after the alarm verification has ended, and verification is enabled for this alarm, the system will start a new alarm verification.

11.8 Resetting alarm message



Notice!

The detector can only be reset once the **Reset** time has elapsed. The reset time is configured via FSP-5000-RPS.

When an element is reset, its initial status is restored. The activation of transmission devices such as fire department or extinguishing devices is reset.

Depending on the configuration, three different variants are offered for resetting:

- Standard
Resetting all message types of the same message type:
All types of messages within the selected message type, such as Fire, are reset.
- Resetting all elements that are not in the normal state
- Displaying a submenu with four different selection options
Each displayed component can be reset individually:
 - **This panel**
To reset all elements that are not in the normal state
 - **All elements in this event**
to reset all elements that have triggered a fire alarm, for example
 - **Logical zone**
a list of the logical zones is displayed
 - **Detector**
a list of the detectors is displayed

To reset an alarm message, select either

- **Reset** on the message display
or
- The alarm message and **Reset** in the detailed view:
Depending on the variant that is offered (see above), all elements that are not in the alarm state or all types of message within the same message type are reset.

If different elements are offered for resetting:

1. Select an element. At the menu items Zone and Detector, a list with all the logical zones and detectors concerned appears.
2. Select the list field you require. Refer to *Scrolling through lists, page 25* for information on how to scroll forward and backward through a list.
The list field is marked.
3. Select **Reset**.
The selected element / element group is reset.

TEXT	R
------	---

If a list field is marked with an R, the process of resetting is not yet complete for this element.

If an element cannot be reset, it will continue to be displayed in the list.

After the successful resetting of all elements, the standby display is displayed.

11.9 Bypassing detectors

**Warning!**

Risk of unrecognized hazardous situations

Bypassing a detector disables its alarm and fault messages. These messages will no longer be displayed on the system.

To bypass a detector that has triggered an alarm:

1. Select the alarm message you require.
2. Select **Bypass**.

12 Fault message

This chapter contains information about the following points:

- *Calling up fault indication, page 47*
- *Fault message on the panel, page 47*
- *Resetting fault message, page 50*
- *Blocking an element, page 51*

12.1 Calling up fault indication

To display the fault messages from the alarm indication or any other menu, select the following on the status bar:

- **Fault:** A list of all reported fault types and the number of faulty elements are displayed.
- **Status:** A list of all current messages, grouped by message type, is displayed. The number of elements is also given in each case.

To display the fault messages, select the message category you require – in this case, Fault.

	0 Fire	0 Control	8 Fault	0 Bypass	Status
---	------------------	---------------------	-------------------	--------------------	---------------

Notes

- If a fire alarm is reported, the system automatically switches to alarm indication. To return to the fault indication, select **Fault** on the status bar. After 30 seconds, the display automatically switches back to alarm indication in the event of a fire.
- If a message does not need to be reset, it is removed from the display once the fault is corrected.
- If individual elements within a group are malfunctioning, the system first displays the element group. To display the individual elements, select the required element group. See also *Displaying individual elements of an element group, page 49*.

12.2 Fault message on the panel

12.2.1 Acknowledging a message

There are two ways to acknowledge messages:

- Acknowledging all displayed messages: Select **Acknowledge**.
- Acknowledging an individual message: First select the message and then press **Acknowledge**.

Element groups

All addressed logical elements are displayed in a list.

List fields with yellow background indicate unacknowledged fault messages.

List fields without distinction indicate acknowledged fault messages.



Notice!

A maximum of four fault messages can be displayed on the display at any time. Only fields that can be operated are displayed (e.g. **Acknowledge** and **Reset**).

To display further fault messages, scroll down through the list.
The next four fault messages are displayed.

12.2.2 Sequence of the fault messages

The messages are displayed in chronological order.



Notice!

15–30 seconds after the last entry (e.g. after scrolling through the list), the first and last fault message is displayed at the beginning of the list again.

12.2.3 Information about malfunctioning element groups

The trouble message contains information about:

- Element category
- Message type
- Address of the element group
- Number of individual elements that have caused a fault in the respective element group
- Message number
- Additional information (e.g. the installation location)

Example:

Fault		Zone	00005	
#001	Office 1			(6)

Element category: Different detectors in one logical zone

Message type: Fault

Address of element groups 00005: The fifth logical zone caused the first fault.

Number of individual elements (6): In the fifth logical zone (00005), six detectors caused a fault. For element groups that only consist of one element, the number of elements is not displayed.

Message number The fault messages are numbered chronologically. The message number in the second line indicates the sequence in which the fault messages were received. 001: The first and oldest fault message received.

Installation location of the logical zone Office 1



Notice!

Depending on the configuration of the system, either the logical or physical address of the element is displayed.

12.2.4 The newest message

The newest message is displayed at the end of the list.



Notice!

15–30 seconds after the last entry (e.g. after scrolling through the list), the first and oldest fault message is displayed at the beginning of the list again.

12.2.5 **Displaying individual elements of an element group**

To display the individual elements in an element group, select the element group you require.

The fault messages of the individual elements are listed.

12.2.6 **Information about individual elements**

The trouble message contains information about:

- Element category
- Message type
- Element address
- Message number
- Additional information (e.g. the installation location)

Example:

Fault		Transmission device	00026-	004
#002	Cafeteria			

Element category: Transmission device

Message type: Fault

Element address: The following transmission device has caused a fault:
00026 - 004: The fourth transmission device (004) in the 26th group (00026).

Message number: The fault messages are numbered chronologically.
The message number in the second line indicates the sequence in which the fault messages were received.
002: The second fault message to be received.

Installation location of the element: Cafeteria



Notice!

Depending on the configuration of the system, either the logical or physical address of the element is displayed.

12.2.7 **Displaying additional information**

To display further information about the individual elements, select the fault message you require.



Notice!

The information displayed is entered in the FSP-5000-RPS programming software.

The following information is displayed:

- Element category
- Message type
- Date and time of the message
- Physical and logical addressing of the element
- Only for LSN detectors: specification of the detector type

- Action text (depending on the configuration)

Select **OK** to return to the list of all fault messages. **Reset**, see *Resetting fault message, page 50*.

Block, see *Blocking an element, page 51*. Select **Details** (if available) to go directly to the respective **Diagnostics** window for troubleshooting, see *Diagnostics, page 58*.

12.2.8

Signals

Optical signals

The  "fault" icon lights up yellow.

Depending on the type of fault, an additional yellow signal light lights up (see also *Status LEDs, page 14*):

-  Fault system (LED steady)
-  Fault power (LED steady)
-  Fault detector (LED blinking)
-  Fault transmission device (LED blinking)
-  Fault signals (LED blinking)
-  Output to fire protection equipment fault (LED blinking)

Acoustic signal

An internal signal tone sounds on the system.

To temporarily silence the internal buzzer:

Press  .

12.3

Resetting fault message



Notice!

If a message does not need to be reset, it is removed from the display once the fault is corrected.

Depending on the configuration, three different variants are offered for resetting; see *Resetting alarm message, page 45*.

There are two ways to reset a fault message:

- Select **Reset** in the message display or
- Select the fault message and then press **Reset** in the detailed view

The selected element/element group is reset.

If a list field is marked with an "R", the process of resetting is not yet complete for this element.

TEXT	R
------	---

If an element cannot be reset, it will continue to be displayed in the list.

After the successful resetting of all elements, the standby display is displayed.

12.4 Blocking an element



Warning!

Risk of unrecognized hazardous situations

Blocking a detector disables its alarm and fault messages. These messages will no longer be displayed on the system.

In order to block an element that has caused a fault:

1. Select the fault message you require.
2. Select **Block**.

13 Bypass

This chapter contains information about the following points:

- *Bypassing and un-bypassing elements, page 52*
- *Displaying and un-bypassing bypassed element groups, page 52*
- *Displaying list of all bypassed elements, page 53*
- *Bypassing/Un-bypassing buzzer, page 53*
- *Bypassing/Un-bypassing the output to fault warning routing equipment, page 54*



Warning!

Risk of unrecognized hazardous situations

Bypassing a detector disables its alarm and fault messages. These messages will no longer be displayed on the system.

13.1 Menu overview

Bypass Block	->	Bypass	->	Show bypassed devices	Select by number		Bypass buzzer	Printer
		Block		NAC	Transmission device		HVAC	Doorholder
				Detector	Logical zone		Extinguishing system	Annunciator
				Bypass group	More...	->	Control element	Interface module

13.2 Bypassing and un-bypassing elements

Select the element you require in the submenu.



Notice!

Partly bypassed elements, such as loops or bypass groups, can be displayed and completely bypassed; see *Displaying and un-bypassing bypassed element groups, page 52*.



Notice!

The menu structure may be different depending on the configuration in FSP-5000-RPS.



Notice!

Depending on the configuration and the structure of the panel, it is possible that signaling devices cannot be bypassed individually but only all at once. In this case, the **NACall** list field is offered instead of a selection list.

13.3 Displaying and un-bypassing bypassed element groups

1. There are two ways to display all partly or completely bypassed loops, logical zones etc.:
 - Select **Bypass** on the status bar
A list of various states is displayed. Or
 - Select **Bypass Block** in the start menu.

2. Select either **Bypassed** or **Bypass** and then **Show bypassed devices**.
A list of various element categories is displayed. The listed number displays the number of bypassed elements or element groups in the relevant element category.
3. Select the list field you require, e.g. logical zone.
4. Select:
 - **Partly bypassed** to display all partly bypassed logical zones
 - **Completely bypassed** to display all completely bypassed logical zonesDepending on which option you select, all partly bypassed or fully bypassed logical zones will be displayed. The number in parentheses, e.g. (5) specifies the number of bypassed elements.
To remove the bypass from all elements in one or more logical zones, select the logical zone you require and select **Un- bypass**.

13.4 Displaying list of all bypassed elements

13.4.1 Using the menu

To display a list of all bypassed elements, select the following in the start menu:

1. **Bypass Block**
2. **Bypass**
3. **Show bypassed devices**
A list of various element categories is displayed. The listed number displays the number of bypassed elements or element groups in the relevant element category.
4. Select the element category you require, e.g. **Detector** .
A list of all bypassed detectors is displayed:
To un-bypass bypassed elements:
 1. Select the element you require.
 2. Select **Un- bypass**.
The element is un-bypassed.

13.4.2 Via the status bar

To display a list of all bypassed elements:

1. Select **Bypass** from the status bar.
A list of various states is displayed.
2. Select **Bypassed**.
A list of various element categories is displayed. The listed number displays the number of bypassed elements or element groups in the relevant element category.
3. Select the list field you require, e.g. Detector.
A list of all bypassed elements is displayed.
To un-bypass bypassed elements:
 1. Select the elements you require.
 2. Select **Un- bypass**.

13.5 Bypassing/Un-bypassing buzzer



Warning!

Risk of life safety and operational failure

If you permanently switch off the internal buzzer, the panel will not produce an acoustic signal for alarms or faults. This may result in missed alerts.

In order to prevent an acoustic warning tone being sent to the panel during maintenance work, for example, the panel's internal buzzer can be permanently bypassed.

To bypass the internal buzzer, select the following in the start menu:

1. **Bypass Block**
2. **Bypass**
3. **More...**
4. **Bypass buzzer**

The buzzer is bypassed and the text on the user interface changes to **Unbypass buzzer**.

To remove the bypass from the buzzer, select **Unbypass buzzer** in step 4.

13.6 Bypassing/Un-bypassing the output to fault warning routing equipment

In the FSP-5000-RPS configuration the fault relay of the ENO 0000 A - Fire Service Interface Module is configured as output to fault warning routing equipment according to EN54-2.

Note: To display and bypass/un-bypass the output to fault warning routing equipment, you have to know the address (**Group** and **Sub-address**) and the label, which have been assigned to the fault relay in the FSP-5000-RPS configuration.

13.6.1 Bypassing the output to fault warning routing equipment

To bypass the output to fault warning routing equipment, select the following in the start menu:

1. **Bypass Block.**
2. **Bypass.**
3. **Select by number.**
4. Enter the address (**Group** and **Sub-address**) that has been assigned to the fault relay in

the FSP-5000-RPS configuration and press the Enter key .

A list of various states is displayed.

5. Select the output to fault warning routing equipment from the list and press **Bypass**.
If necessary, enter your user ID and password to log on to the panel controller.
The output to fault warning routing equipment is bypassed.

13.6.2 Un-bypassing the output to fault warning routing equipment

There are two ways to un-bypass the output to fault warning routing equipment:

- Un-bypassing using the start menu
- Un-bypassing via the status bar

Un-bypassing using the start menu

To un-bypass the output to fault warning routing equipment using the start menu, select the following:

1. **Bypass Block.**
2. **Bypass.**
3. **Show bypassed devices.**

A list of various element categories is displayed.

4. Select the output to fault warning routing equipment from the list and press **Un-bypass**.

If necessary, enter your user ID and password to log on to the panel controller.

The output to fault warning routing equipment is un-bypassed.

Un-bypassing via the status bar

To un-bypass the output to fault warning routing equipment via the status bar, select the following:

1. **Bypass.**
A list of various states is displayed.
2. **Show bypassed devices.**
A list of various element categories is displayed.
3. Select the output to fault warning routing equipment from the list and press **Un-bypass.**
If necessary, enter your user ID and password to log on to the panel controller.
The output to fault warning routing equipment is un-bypassed.

14 Block

This chapter contains information about the following points:

- *Blocking and unblocking elements, page 56*
- *Displaying list of all blocked elements, page 56*



Warning!

Risk of unrecognized hazardous situations

Blocking a detector disables its alarm and fault messages. These messages will no longer be displayed on the system.

14.1 Menu overview

Bypass Block	->	Bypass		Show blocked devices	Select by number		Block group	Printer
		Block	->	Sounder	Strobe		HVAC	Doorholder
				Transmission device	Detector		Extinguishing system	Annunciator
				Logical zone	More...	->	Control element	Interface module

14.2 Blocking and unblocking elements

Select the element you require in the submenu.

Example:

To block a detector, select the following in the start menu:

1. **Bypass Block**
2. **Block**
3. **Detector**

Various selection criteria are displayed. See also *Working with lists, page 24*.

4. Select a selection criterion, e.g. **By description**.
A list of the detectors is displayed. Refer to *Scrolling through lists, page 25* for information on how to scroll forward and backward through the list.
5. Select the required list fields.
The list fields are marked.
6. Select **Block**.

The selected elements are blocked.

To unblock the elements again, repeat all previous steps but select **Un-block** in step 6.



A C after a detector means that this detector is part of a closed group and cannot be blocked individually. In order to block a detector marked in this way, please select **Logical zone** in step 3.

14.3 Displaying list of all blocked elements

14.3.1

Using the menu

To display a list of all blocked elements, select the following in the start menu:

1. **Bypass Block**
2. **Block**
3. **Show blocked devices**

A list of various element categories is displayed. The listed figure indicates the number of blocked elements or element groups in the relevant element category.

4. Select the element category you require, e.g. **Detector** .

A list of all blocked detectors is displayed.

To unblock elements:

1. Select the element you require.
2. Select **Un- block**.

The element is unblocked.

14.3.2

Via the status bar

To display a list of all blocked elements:

1. Select **Bypass** from the status bar.

A list of various states is displayed.

2. Select **Blocked**.

A list of various element categories is displayed. The listed figure indicates the number of blocked elements or element groups in the relevant element category.

3. Select the list field you require, e.g. **Detector** .

A list of all blocked elements is displayed.

To unblock elements:

1. Select the element you require.
2. Select **Un- block**.

The element is unblocked.

15 Diagnostics

This chapter contains information about the following points:

- *Element details, page 58*: Diagnostic information about an LSN module and about elements of a selected LSN module
- *Modules, page 59*: Diagnostic information (software version) and hardware diagnostic data about modules
- *Hardware, page 59*: Diagnostic information about:
 - *LED test, page 59*
 - *Display test, page 59*
 - *Trace information, page 60*
 - *CAN-Bus, page 61*
- *Panel passport, page 61*: Diagnostic information about the panel controller
- *LED Test on modules, page 61*: Testing the LED display of modules
- *Network services, page 62*: Information on the availability of other nodes within the system network
- Voice alarm systems: Diagnostic information about a connected voice alarm system (VAS)

15.1 Menu overview

Diagnostics	->	Element details	Modules
		Hardware	Panel passport
		LED test on modules	History log
		Network services	VAS

15.2 Element details

To display diagnostic information about the elements in a particular module:

1. In the start menu, select **Diagnostics**
2. **Element details**

A list of the LSN modules is displayed.



Notice!

The numbers before the module names indicate the slot of the module on the panel.

1. Select the list field you require.
On the display, various possibilities for selection are offered:
2. Select:
 - **All info for one element** to display all diagnostic information about an element on one loop of an LSN module.
 - **Info for element group** to display particular diagnostic information about several elements of the selected LSN module.
 - **Info for all elements on the module** to display particular diagnostic information about all LSN elements of the selected LSN module.

The subsequent procedure for all three selection possibilities will be presented by means of an example. The other two possibilities deviate only slightly from this.

Example:

1. Select **Info for element group**.
A list of the elements of the selected LSN module is displayed.
2. Select the required list fields.
The list fields are marked.
3. Select **Yes**.
A list of various data types is displayed.
4. Select the field you require.
The field is marked.
The data of each selected element is requested.
5. Select **Start**.
To cancel the operation, select **Cancel**.
A status bar appears.
6. Select the arrow keys to display further information.
7. Select **Refresh** to update data if necessary.

15.3

Modules

To display diagnostic information about a particular module:

1. In the start menu, select **Diagnostics**
2. **Modules**
Two different lists are offered.
3. Select a list, e.g. **By number**. Refer to chapter Scrolling through lists for information on how to scroll through a list.
A list of all used modules is displayed.
4. Select the list field you require.
A list of various information options is displayed:
 - **Module passport**
 - **Module Compatibility**
 - **Module status**For an LSN module, the following selection fields are also offered:
 - **Module status and counters**
 - **Reset counters**
5. Select the information option you require, e.g. **Module status**.
Diagnostic information about the module status is displayed.
A status bar appears.
6. Select the arrow keys to display further information.
7. Select **Refresh** to update data if necessary.

15.4

Hardware

15.4.1

LED test

To test the LEDs in the LED display:

1. In the start menu, select **Diagnostics**.
2. Select **Hardware**.
3. Select **LED test**.
For the duration of approximately five seconds, all LEDs on the LED display light up.

15.4.2

Display test

To test the operativeness of the display:

1. In the start menu, select **Diagnostics**.
2. Select **Hardware**.
3. Select **Display test**. These are the results:
 - The buzzer and all indicators on the panel controller and functional modules are switched on for a short time.
 - A part of the display is sequentially filled with the colors white, black, red, green and blue.
 - The display returns automatically to the **Hardware** menu.

15.4.3

Trace information

The panel can save trace files on a memory card, which is useful for expert analysis when the system behaves unexpectedly. The panel can handle memory cards up to 2TB in size. If you use a memory card with a large capacity, for example 2TB, then the period for gathering trace information will be longer. To get the most trace information possible, use an empty memory card.



Caution!

Risk of data integrity

Do not remove the memory card while the panel gathers trace information. This may corrupt trace files and result in incomplete data.

To start gathering trace information, follow these steps:

1. From the home menu, select **Diagnostics**.
2. Select **Hardware**.
3. Select **Trace information**.
4. Get a memory card that is FAT32 formatted.
5. Disable the write protection of the memory card.
6. Insert the memory card into the panel controller's slot.
7. Press **Start**.
A message confirms that the panel is gathering trace information.
8. Let the system run for a period recommended by the technical support engineer.
9. Press  to exit and to return to the home menu.

If the memory card is invalid, please double-check the following:

- Ensure that the write protection of the memory card is disabled.
- Ensure that the capacity of the memory card does not exceed 2TB.
- Verify that the memory card is formatted as FAT32.

For more information, refer to the system manual chapter 5.3 Formatting memory cards in FAT32.

To stop gathering trace information, follow these steps:

1. From the home menu, select **Diagnostics**.
2. Select **Hardware**.
3. Select **Trace information**.
A message confirms that the panel is gathering trace information.
4. Press **Stop**.
A message confirms that the trace information is stored on the memory card.
5. Remove the memory card when the panel displays the message: **Please remove the memory card**.
6. If another process is still writing information on the memory card, make sure to stop that process before removing the memory card.

7. Press  to exit and to return to the home menu.

To send the trace files to the technical support, follow these steps:

1. The memory card contains one or more directories Pxxxxxxxxxxxx where xxxxxxxxxxxx is an arbitrary hexadecimal number. Copy all these directories to the local hard disk of a computer.
2. Create an archive containing these directories, for example zip or tar.gz.
3. Send the archive to the technical support.



Notice!

Do not remove or rename files.

15.4.4

CAN-Bus

Select **CAN bus** to display the status of the CAN interfaces.

15.5

Panel passport

Select **Panel passport** to display the following diagnostic information:

- **Device:** e.g. AVENAR panel 8000
- **License:** Premium/Standard
- **Redundancy mode:** Master/Redundant
- **Production date:** e.g. 1 September 2020
- **Serial number:** e.g. 0431162077011100130
- **Material number:** e.g. F01U352441
- **BOM revision:** e.g. A.11
- **Firmware type:** Official release/Private
- **Firmware version:** e.g. 4.3.0
- **Hardware version:** e.g. 0-009-016
- **MAC 0 address host:** e.g. 00:04:63:6D:A1:42

15.6

LED Test on modules

To test the LED display of selected modules:

1. In the start menu, select **Diagnostics**
2. **LED test on modules**

A list of various selection criteria is offered:

- Select **LED test all modules** to test the LED display of all modules.
- Select **By number** or **By type** to test the LED display of individual selected modules.

Example

To test the LED displays of an LSN 300 module:

1. Select **By type**.
A list of all module types is displayed.
2. Select the LSN 300 module.
A list of all LSN 300 modules is displayed.
3. Select the list field(s) you require. The list fields are marked.
4. Select **Activate LEDs**.
The LEDs are activated for the duration of approx. five seconds.

**Notice!**

The numbers before the module names indicate the slot of the module on the panel.

15.7 Network services

15.7.1 Routing table

To display routing information:

1. In the start menu, select **Diagnostics**
2. **Network services**
3. **Routing table**

A table with routing information is displayed.

All networked nodes that can be reached via the node currently being operated and that are recognized within the system network are displayed under **Node**.

CAN1 to USB1 designate the interfaces on the currently operated panel node. In this example, it is the node 1 interfaces.

The type of interface on the panel node currently being operated is listed under **interface**.

The following interfaces can be designated:

- CAN 1 interface
- CAN 2 interface
- Ethernet 1 (IP multicast or UDP tunnel)
- Ethernet 2 (IP multicast or UDP tunnel)
- Ethernet 3 (IP multicast or UDP tunnel)
- Ethernet 4 (IP multicast or UDP tunnel)
- USB 1 interface

The number of nodes that need to be passed in order to reach the listed node is entered under **distance**. For nodes that are directly reachable via IP multicast, the value is 1; for nodes that are connected via other interfaces (e.g. CAN) to nodes reachable via IP multicast, the value is increased in increments accordingly (e.g. connected via IP multicast + CAN1/CAN2, value = 2).

A physical node number from 1 to 64 can be assigned to panels.

15.7.2 Consistency check

Inconsistencies between the network settings configured in FSP-5000-RPS and those set in the panel controller are displayed under **Diagnostics - Network services -**

Consistency check.

1. In the start menu, select **Diagnostics**
2. **Network services**
3. **Consistency check**

Where inconsistencies are identifiable between the network settings saved in the panel controller and those configured in FSP-5000-RPS, these are indicated. You can use the arrow key on the display to alternate between displaying **Problems of active configuration:** and **Problems expected after restart:**.

Problems of active configuration:

The table indicates inconsistencies between the network settings of the panel controller's active configuration ("**active**") and the settings configured in RPS ("**configured**").

Problems expected after restart:

The table indicates inconsistencies between the network settings that have already been configured on the panel but which do not take effect until restart ("**saved**") and the settings configured in RPS ("**configured**").

15.7.3 Ethernet ports

To display a table listing the various parameters and the status of the two Ethernet ports:

1. In the start menu, select **Diagnostics**
2. **Network services**
3. **Ethernet ports**

Information on Ethernet port 1 is displayed.

You can use the arrow key on the display to switch to details of Ethernet port 2, port 3 and port 4.

To update the information displayed, select **Refresh**.

Information on the following parameters is displayed in the table:

- **Port status**
- **Link status:** Checks the operativeness of the network cable
- **Speed:** Speed of the network connection
- **#Tx Frames:** Number of transferred data packages
- **#Rx Frames:** Number of received data packages
- **Connected to:** Indicates neighboring available node

15.7.4 Send ping command

To check the availability of other nodes in the network, a ping command can be sent to a specific IP address:

1. In the start menu, select **Diagnostics**
2. **Network services**
3. **Send ping command**
4. Enter the IP address of the network node you wish to assess as regards availability and select **Send ping command**.

To enter an IP address:

Touch the field containing the IP address. Use the arrow keys on the operating panel to select the individual numbers and modify using the number keys on the alphanumeric keypad.

Or:

Touch the **Change** field. Touch the field containing the number block to be changed. Use the arrow keys on the operating panel to select the desired number and modify using the number keys on the alphanumeric keypad.

If the addressed network node is accessible, a success message is displayed.

15.7.5 Remote Services

The Remote Services help the user to monitor and maintain the fire panel.

Preconditions

- **Secure Network Gateway:** Provides a plug-and-play connection to the fire system's Ethernet port via Fire System Explorer.
- **Fire System Explorer (FSE):** Is the cockpit to access the Remote Services. On the FSE [website](#) you can create a company account (tenant) to connect each panel to the account by using its Remote ID. The Remote ID is a unique number representing the tenant.

- **Remote Connect:** Enables remote access to the panel through the remote programming software FSP-5000-RPS.

Available Remote Services:

1. Remote Alert

With Remote Alert, the panel sends status information automatically to the Fire System Explorer.

Remote Alert analyzes the data and informs the user by email about unexpected events.

The **Remote Fire Safety app** is part of Remote Alert. It provides:

- Push notifications for alarms and system warnings.
- Access to historical notifications that can be shared via email or messenger.
- Updates on system status: Health connectivity, license, and firmware.
- Precondition: Users must have an account on the Fire System Explorer.

The app is free to download for iOS and Android:

- [App Store](#)
- [Google Play](#)

2. Remote Maintenance

Remote Maintenance monitors parameters of security items connected to the fire panel.

It collects data of relevant LSN devices and functional modules.

Data is sent to the Fire System Explorer for analysis and maintenance planning.



Notice!

For more information about how to set up a connection to Remote Services, refer to the networking manual.



Notice!

In Germany, you must have a service agreement with Bosch Energy and Building Solutions to use Remote Maintenance.

Features and status of Remote Services

The Remote Services window shows details about the features and status of Remote Services.

To open the Remote Services window:

1. Go to the start menu.
2. Select: **Diagnostics** -> **Network services** -> **Remote Services**.

The window displays a list with information about the configured features. To see all information in the list, scroll down.

Displayed information:

System name:

- The name is configured in the Remote Services window of the FSP-5000-RPS.
- If no name is set, the panel serial number is used as the system name.

Remote ID:

- A unique identification number for a specific service contractor.
- The Fire System Explorer generates and provides the Remote ID.
- To add or change the Remote ID, refer to *Remote Services*, page 83.

System ID:

- Identifies one AVENAR system in an FSP-5000-RPS configuration.
- The Fire System Explorer assigns this ID to the fire panel.

Status Remote Services:

- Shows if a remote connection to the Fire System Explorer is configured. (**Enabled/ Disabled**).

Connection state:

- Available only on the gateway panel.
- Shows the connection to the Fire System Explorer (**OK/Waiting for feedback/ Connection failed**).

State of Remote Maintenance: / State of Remote Alert:

- Shows if the respective feature was activated in FSP-5000-RPS.

RM/RA: State of last transfer: (RM: Remote Maintenance;RA: Remote Alert)

- Shows the status via an HTTP code of the last data transfer to the cloud:
OK - HTTP 200
Failed - any other HTTP code

RM/RA: Date of last transfer:

- Shows the date and time of the last data transfer from an LSN device connected to the fire panel to the Fire System Explorer.

Connect to server:

- If the panel has a Remote ID, it automatically tries to connect to the Fire System Explorer.
- To manually connect, select **Connect to server**.

For access type Remote Assistance:

Server IP address:

- The IP address of the server collecting and receiving data.

Server port: .

- The port number of the server collecting and receiving data.

15.8 Voice alarm systems (VAS)

Two different kinds of voice alarm systems can be connected to the AVENAR panel 8000/2000 using Smart Safety Link:

- VAS through serial interface module (Plena)
- VAS over IP (PRAESENSA, PAVIRO, Praesideo)

The diagnostic information displayed depends on the voice alarm system configured for the AVENAR panel 8000/2000.

1. In the start menu, select **Diagnostics**.
2. Select **VAS**.

One of the following VAS will be displayed:

15.8.1 Plena

The following information is displayed:

- Trouble (yes/no)
- Emergency (yes/no)
- Failure (yes/no)
- Internal monitoring (yes/no)
- Supervision time (sec).
- Boot-up phase is finished (yes/no)
- Failure at controller (yes/no)
- Failure at router (yes/no)

15.8.2 PRAESENSA / PAVIRO / Praesideo

License: Software check if the fire panel contains a premium license.

- **OK:** Premium license is available.
- **Missing:** Premium license is not available. Exchange standard license by premium license.
- **Disconnection in x hours:** In case the premium license is missing, the system will automatically interrupt the connection to the VAS after 72 hours. The counter shows the remaining time.

Status: Shows if the panel has established a connection to the VAS.

- **Connected:** Connection is established.
- **Disconnected:** Connection is not established.

Fault: English error message of the fire panel OIP, TLS or TCP connection. Visible in case of

Status: Disconnected.

VAS Status: Shows if the connected VAS has reported a fault condition.

- **n/a:** Not possible to execute the check, for instance due to interrupted connection.
- **OK:** No fault condition is reported by the VAS.
- **Fault:** The connected VAS reports a fault condition. Check the VAS. Reset the fault on the VAS.

Triggers: Software check if the configured virtual VAS triggers are available as virtual inputs in the VAS configuration.

- **n/a:** Not possible to execute the check, for instance due to interrupted connection.
- **OK:** All virtual VAS triggers are available as virtual inputs in the VAS.
- **Mismatch:** Virtual VAS triggers are not corresponding to the virtual inputs available in the VAS. Verify the configuration.

Certificate:

- Unique SHA-1 fingerprint to identify which encryption certificate is available in the fire panel.
- This string must match the string shown on FSP-5000-RPS and the connected VAS.
- Only the first 30 characters from a total of 40 characters are shown.
- Only visible in case of an encrypted connection.

Compatibility: Shows if the firmware version of the connected VAS is released for the connection to a fire panel.

- **n/a:** Not possible to execute the check, for instance due to interrupted connection.
- **OK:** VAS is suitable.
- **Warning:** Check the firmware version of the VAS.

Service: Shows if the panel has access to the OIP service.

- **OK:** OIP service is running on the fire panel
- **Disconnected:** OIP service is not running. Reset the fire panel through the user interface.

Faults: Shows the number of connection faults of the interface since the last reboot of the fire panel.

IP address: Configured IP address of the VAS.

Port #: Configured port number of the VAS.

- 9401: Port number for Praesideo and PAVIRO
- 9403: Port number for PRAESENSA

To check the availability of the VAS, press the **Send ping command** button.

16 Maintenance

This chapter contains information about the following points:

- Walktest: see *Maintenance – walktest*, page 69
- *Change language*, page 67
- *Activate Outputs*, page 67
- *Activate Transmission Device*, page 68
- Detector removal
- History Log: see *Maintenance – history log*, page 73
- *Bypassing/Un-bypassing buzzer*, page 68

16.1 Menu overview

Maintenance	->	Walktest	Change language
		Activate outputs	Activate transmission device
		History log	Bypass buzzer

16.2 Change language



Notice!

The fastest way to change the language display is via a shortcut; see also *Changing language display*, page 28.

There are two ways of selecting a different language display:

- Using the menu
- Entering a shortcut; see *Changing language display*, page 28.



Notice!

After the system starts up following a power cut or battery failure, the default language defined in the FSP-5000-RPS programming software is set again.

Making a selection via the menu

1. In the start menu, select **Maintenance**
2. **Change language**
A list of the languages which can be selected is displayed.
3. Select the language you require.
The displays are displayed in the selected language.

16.3 Activate Outputs

1. In the start menu, select **Maintenance**
2. **Activate outputs**
Various element categories are displayed.
3. Select a category or **Select by number** and enter the number of the element into the search screen; see also *Search Function/Element*, page 26
4. Select the required list fields. The list fields are marked.
5. Select **On** to activate the selected notification appliances.
The selected signaling devices are activated.
6. Select **All** to activate all notification appliances.

7. To end activation of the selected elements, repeat the same steps but select **Off** in step 5.

**Notice!**

In the **HVAC** element category, the **Auto** function field is also offered. Select this function field to assign automatic mode to a fan, for instance.

16.4 Activate Transmission Device

To activate a transmission device:

1. In the start menu, select **Maintenance**
2. **Activate transmission device**
A list of the elements is displayed. Refer to *Working with lists, page 24* for information on how to navigate through a list.
3. Select the required list fields.
The list fields are marked.
4. Select **On**.
The selected transmission devices are activated.

To end activation of the selected elements:

1. In the start menu, select **Maintenance**
2. **Activate transmission device**
3. Select the list fields of the activated transmission devices.
4. Select **Off**.
The transmission devices are no longer activated.

16.5 Bypassing/Un-bypassing buzzer

In order to prevent an acoustic warning tone being sent to the panel during maintenance work, for example, the panel's internal buzzer can be permanently bypassed.

To bypass the internal buzzer, select the following from the start menu:

1. **Maintenance**
2. **Bypass buzzer**

The buzzer is bypassed and the text on the user interface changes to **Unbypass buzzer**.

To remove the bypass from the buzzer, select **Unbypass buzzer** in step 2.

**Notice!**

If you switch the internal buzzer off permanently, no acoustic signal will sound on the panel in the event of an alarm or fault!

17 Maintenance – walktest



Notice!

Terminology

The term **Walktest**, which is used in the fire panel and in the documentation, corresponds to the EN54-2 standard term **Test condition**.

This chapter contains information about the following points:

- *Walktest groups, page 69*
- *Starting and ending walktest, page 71*
- *Ending walktest for all elements, page 72*
- *Displaying tested or untested elements, page 72*
- *Assigning tested elements to a walktest group, page 72*

A walktest is indicated by a yellow LED display on the panel.



Caution!

Risk of missed alarm

If a detector is in walktest mode, the system does not forward alarm or fault messages to transmission devices or extinguishers.



Notice!

If the system activates a signaling device during a walktest, the device emits a different signal tone than in the alarm state.

17.1 Walktest groups

The following options are available for switching elements to walktest:

- Select individual elements from lists and/or
- Select previously defined walktest groups consisting of at least one element.

There are 12 pre-defined walktest groups. The number of possible walktest groups is predefined: January to December.

Example:

Detectors which are to be tested in May, can be grouped together in a group called May. New elements can be added to a group, and elements that have already been added can be removed.



Notice!

Even if the elements in a group (e.g. January) have been completely deleted, this group will still be displayed in the list.

17.1.1 Adding or deleting elements

In order to add elements to a walktest group or remove elements from it:

1. In the start menu, select **Maintenance**
2. **Walktest**
3. **Create / Change walktest group**
A list of the walktest groups is displayed.
4. Select a walktest group, e.g. February.
You can choose from a number of options:
 - **Delete all:** Delete all elements in the selected group.

- **Show / Change:** Delete all elements in the selected walk test group and delete individual elements.
- **Add:** Display all elements that have not yet been assigned to a walk test group, and add individual elements.
- **Cancel:** Cancel the operation.

**Notice!**

The deleted elements are assigned to the **Unassigned elements** group.

Toggle function

New elements can be added and existing elements deleted in every submenu.

Add

When one of the function fields is selected, the display changes and a new function can be performed.



Select this function field to add one or more new elements.

Only those elements which have not been assigned to any walktest group yet will be displayed.

Various element categories are displayed.

1. Select the category you require.
A list of elements is displayed. See also *Working with lists, page 24*.
2. Select an element.
The element is marked.
3. Select **Add**.
The selected element is added to the group.

Delete

Select this function field to delete one or more elements.

Only elements from the selected walktest group are displayed.

1. Select an element.
The element is marked.
2. Select **Delete**.
The selected element is deleted from the group.

Example:

1. Select **Show / Change**.
To delete one or more element(s) from the selected group:
2. Select one or more list fields.
The list fields are marked. Refer to *Scrolling through lists, page 25* for information on how to navigate through a list.
3. Select **Delete**.
The element is deleted from the selected group. The list field is no longer displayed.

In order to add new elements:

1. Select **New**.
The display changes. Various element categories containing elements which have not been assigned to any walktest group yet are displayed.
2. Select the element category you require.
3. Select one or more list fields.
The list fields are marked.
4. Select **Add**.
The selected element is added to the selected walktest group.

Change name

To change the name of the input or output group:

1. Overwrite the name; see *Entering numbers and text*, page 27.
2. Select **OK**.
The new name is confirmed.

17.2 Starting and ending walktest



Notice!

The information about the date and time of every walktest is stored in the history log. You can print this information on a printer. See *Maintenance – history log*, page 73.

17.2.1 Starting the walktest

To select the elements for the walktest and to switch them to walktest:

1. In the start menu, select **Maintenance**
2. **Walktest**
3. **Start / End walktest**
Various element categories are displayed.
4. Select:
 - **More...** to display further categories or
 - one of the displayed categories or
 - **Select by number** and enter the number of the element into the search screen; see also *Search Function/Element*, page 26.



Notice!

If you select the element category **Loop**, **Logical zone**, **Detector** or **Walktest group**, you will be asked to select the type of walk test. Select **Sequential walktest** to check each individual sensor (optical, chemical or thermal) of the detectors you are testing, or select **Simultaneous walktest** to test combination detectors using a test device with combined trigger substances for simultaneous testing of multiple sensors.

Example:

1. Select **Walktest group**.
2. Select **Sequential walktest** or **Simultaneous walktest**
A list of walktest groups is displayed. Refer to *Scrolling through lists*, page 25 for information on how to navigate through a list.
3. Select the list field you require.
The field is marked.
4. Select **On**.
The selected walktest group is switched to walktest.

17.2.2 Ending the walktest

To end the walktest for this walktest group:

1. Mark the selected walktest group.
2. Select **Off**.

17.3 Ending walktest for all elements

To end the walktest for all walktest groups and elements:

1. Select **End** from the status bar.
Various possibilities are offered on the display:
2. Select **Yes** in order to end the walktest for all walktest groups and elements. Select **No** to cancel the operation and return to the previous display.
The walktest is ended for all walktest groups.

17.4 Displaying tested or untested elements



Notice!

You can choose to display either the untested or tested elements in the current walktest.

Select **Exit** from the status bar.

The following options are offered for the walktest currently being performed:

- Select **Not tested** to display the elements that showed no reaction during the test or that have not been tested.
- Select **Tested** to display the elements that were tested and showed a reaction.

17.5 Assigning tested elements to a walktest group



Notice!

Only those elements in the current walktest that have been tested can be assigned to a different walktest group.

On completion of the walktest, you can assign the tested elements to a different walktest group (for the next walktest, for example):

1. Select **Exit** from the status bar.
Various possibilities are offered on the display:
Select **Assign tested elements to walktest group** to assign the tested elements from the current walk test to a walk test group for the next walk test:
A list of the walktest groups is displayed.
2. Select a walktest group from the list. Refer to *Scrolling through lists, page 25* for information on how to navigate through a list.
Two possibilities are offered on the display:
 - Select **Add to walktest group** to assign the tested elements from the current walk test to a selected walk test group.
 - Select **Overwrite walktest group** to replace the elements in the selected walk test group with the tested elements from the current walk test.

18 Maintenance – history log

In the history log, all data about particular events or device types is stored sorted by date and time. To display only particular data, filters can be set.

In addition to a menu overview, this chapter contains information about the following points:

- *Selecting filters, page 73*
- *Setting filters, page 73*
- *Change Filter, page 74*
- *Combining several filters, page 74*
- *Status bar functions, page 74*
- *Printing out data, page 74*

18.1 Selecting filters

The following filters are available:

Filter	Data, filtered by...
Without filter	All data
Show all Delete filter	Display all data with specification of event number, date, time, element number and message type. Existing filters are deleted.
Period	Starting date, end date and time
Event types	Message types, such as Fault
Device types	Device types, such as Detectors
Address range	Address range within a system
User commands	Selected function fields, such as Acknowledge or Reset .
Walktest	Elements switched to walktest mode

If one or more filters have been set, the **Change filter** field in the status bar is highlighted in a dark color.

18.2 Setting filters

To display only particular data, a filter can be set.

Example:

To display only data that was stored in connection with a particular event, such as Fault:

1. In the start menu, select **Maintenance**
2. **History log**
3. Select the **Event types** filter.
A list of all event types is displayed.
4. Select a list field, e.g. **Fault**.
In the status bar, the **Change filter** field has a black background. See also *Change Filter, page 74*.
5. Select **Show in history log**.
A list of all fault messages is displayed. The events are sorted in ascending order by date and time.
The fault messages are numbered chronologically. The leading number indicates the sequence in which the fault messages were received.

18.3 Change Filter

On each filter menu, another filter can be set using the status bar:

1. Select **Change filter** from the selection bar below.
The various filters are displayed.
2. Select one of the filters displayed.
A list with filtered data is displayed.

18.4 Combining several filters

It is possible to set several filters and to display all filtered data in a list:

To combine the **Device types** filter with the **Message types** filter:

1. Select **Maintenance** from the start menu
2. **History Log**
3. Select a filter, e.g. **Device types**.
4. Select **Change filter** in the selection list.
5. Select the desired device types from the displayed list.
6. Repeat steps 4 to 5 until all desired filters have been selected.
To display all filtered data of the combined filters:
7. Select **Show filter result**.

18.5 Status bar functions

The following functions are offered:



To switch to the status bar on the start page, press the "double arrow" key in the status bar or on the alphanumeric keypad.

Change filter

If the field has a black background, a filter has been set. Select this field to set a different filter.

Go to no.

Enter the number of a specific event.
The event with the selected number is displayed at the start of the list.

Go to day

Enter a date.
All events with the selected date are displayed in the list.

Print

Print the complete displayed list or only a part of it.

Exit

End the entry and switch to the menu overview for the **Maintenance** menu.

18.6 Printing out data

Either the complete list or a specific part of it can be printed out.

To print out data that is displayed on a list:

1. Select **Print** from the status bar.
Two possibilities are offered:
 - **Entire list:** The complete list is selected.
To print the list, continue with step 6.
 - **Define range:** Specify a particular area within the list.

The following two possibilities are available to specify the area of the list to be printed out:

- Limit the number of events, counted from the newest event.
 - Specifying a particular area via the entry of the event numbers.
2. Select **Define range**.
Two possibilities are offered on the display.
 3. Activate the checkbox in front of one of the two options:
 - **Number of events to be printed starting from latest event:**
For the printout, enter a particular number of events, counted from the most recent event.
 - **Event numbers to be printed:**
To print out a particular range, specify by entering event numbers.
A checkmark is placed in the selection field.
 4. Enter the numbers you require.
 5. Select **OK** to confirm the entry.
A list of the printers that can be selected is displayed.
 6. Select a printer.
 7. Select **Print**.
The list is printed.

Event numbers

To display the event numbers again:

1. Select **Show event numbers**.
2. To exit the display, press .

19 Day and night mode

This chapter contains information about the following points:

- Switching between day and night mode
- Changing the time for resetting to night mode

The manner in which an incoming alarm is handled depends on whether the system is in day or night mode; see *Fire alarm*, page 42.



Notice!

Night mode is the highest security level. The system forwards every incoming alarm to external stations.



Notice!

Depending on the security level in question, not all detectors can be switched to day mode.

The following symbols on the status bar show which mode the panel is switched to. In the case of networked panels, a night-/day combination icon is displayed on panels in night mode, if at least one panel in the network is in day mode.

		Standalone	Network
	Night mode	Panel is in night mode	All networked panels in the network scope are in night mode
	Day mode	Panel is in day mode	-
	Night-/day combination	-	Panel is in night mode but at least one other panel in the network scope is in daymode



Notice!

After a transmission fault, you may need to manually synchronize the day/night mode of other panels to display the correct mode..

19.1 Switching between day and night mode



Notice!

Depending on the programming, the panel automatically switches from day to night mode at the preset time.

There are two ways to switch between day and night mode:

- Switching over via the menu
- Switching via the status bar

Switching over via the menu

Depending on the mode to which the panel is switched, **Switch to day mode** or **Switch to night mode** is displayed in the start menu.

1. The panel is in night mode: Select **Switch to day mode** to switch to day mode:

2. Confirm your selection with **Switch to day mode**.

The panel is switched to day mode.


To cancel the operation, select **Cancel**.

If the panel is in day mode, select **Switch to night mode** to switch to night mode.

Switching via the status bar

The panel is in night mode. To switch it to day mode:

- ▶ Press



- ▶ Select **Switch to day mode** to confirm the request or **Cancel** to cancel the operation.

The panel is in day mode. To switch it to night mode:

- ▶ Press



- ▶ Select **Switch to night mode** to confirm the selection or **Cancel** to cancel the operation.

19.2 Showing details

It is possible both in day and night mode to display a list of all logical zones on the panel that are currently switched to day mode.

To display a list of all detector groups in day mode

1. In the start menu, select **Switch to day mode** or **Switch to night mode**, depending on which mode the panel is currently in, or select the "day mode" or "night mode" icon on the status bar.
2. Select **Show details**.

A list of all logical zones that are switched to day mode is displayed.

19.3 Changing the time for switching to night mode




Notice!

The setback time for the current day can be changed by the operator. A change is only possible if a setback time for the current day has been configured in FSP-5000-RPS. After a panel restart, the setback time configured in FSP-5000-RPS is applied. If necessary, re-adjust the setback time.

The set back time can be changed in day or night mode.

To change the time for resetting in night mode:

- ▶ On the status bar, select



or

In the start menu, select **Switch to day mode**.

1. Select **Change time**.

2. Enter the numbers you require.
Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The entries are confirmed.

To change the set back time in day mode to night mode:

1. On the status bar, select



2. or
In the start menu, select **Switch to night mode**.
3. Select **Change time**.
4. Enter the numbers you require.
Select **OK** to confirm the entry or **Cancel** to cancel the operation.

20 Configuration

This chapter contains information about the following points:

- *Physical node address (PNA/RSN), page 79*
- *Group setting, page 79*
- *Detector sensitivity, page 81*
- *Operator, page 81*
- *Rename elements, page 83*
- *Network services, page 83*
- *Overview, page 84*

20.1 Menu overview

Configuration	->	Set Physical Node Address (PNA/RSN)	Set groups
		Detector sensitivity	Operator
		Rename elements	Overview
		Network services	About ...

20.2 Physical node address (PNA/RSN)

The physical node address (RSN) of the panel is set in the panel firmware when switching on the panel for the first time, there are no mechanical rotary switches. It must be identical with the physical node address configured in the programming software. After a change of the physical node address (RSN), a reboot of the panel is required.

To change the physical node address enter a number between 1 and 64. Choose **OK and reboot** to make the change effective.

20.3 Group setting

Different kind of groups can be created using the FSP-5000-RPS programming software: Bypass, isolate and walktest groups and input / output groups.

Each group can consist of one or more element(s).

Input groups consist of several detectors and/or logical zones; Output groups consist of signaling devices and transmission devices. Specify which input group activates which output group by using the programming software.

You can use the panel controller to carry out the following:

- Adding elements to or removing elements from groups.
- Renaming groups.

20.3.1 Adding or deleting

In order to add elements to a group or remove elements from it:

1. In the start menu, select **Configuration**
2. **Set groups**
3. Select the required type of group.
Two different lists are displayed.
4. Select a list, e.g. **By description**.
A list of the various input groups is displayed.
5. Select the list field you require.
The list field is marked.

You can select various options:

- **Delete all:** Delete all elements in the selected input group.
- **Show / Change:** Display all elements in the selected input group and delete individual elements.
- **Add:** Display all elements that have not yet been assigned to an input group, and add individual elements.
- **Cancel:** Cancel the operation.

To change the name of the input group, see Change name.

Walktest Group

To display the elements in a walktest group and to delete or add elements, see *Walktest groups*, page 69.

Toggle function

New elements can be added and existing elements deleted in every submenu.

When one of the function fields is selected, the display changes and a new function can be performed.

Add



Select this function field to add one or more new elements.

Only those elements that have not yet been assigned to an input group will be displayed.

Various element categories are displayed.

1. Select the category you require.
A list of elements is displayed.
2. Select an element.
The element is marked.
3. Select **Add**.
The selected element is added to the group.

Delete



Select this function field to delete one or more elements.

Only elements from the selected input group are displayed.

1. Select an element.
The element is marked.
2. Select **Delete**.
The selected element is deleted from the group.

Example:

1. Select **Show / Change**.
To delete one or more element(s) from the selected group:
2. Select one or more list fields.
The list fields are marked.
3. Select **Delete**.
The element is deleted from the selected group. The list field is no longer displayed.

In order to add new elements:

1. Select **New**.
The display changes. Various element categories containing elements which have not been assigned to any walktest group yet are displayed.
2. Select the element category you require.
3. Select one or more list fields.
The list fields are marked.
4. Select **Add**.
The selected element is added to the selected walktest group.

Refer to

- *Scrolling through lists, page 25*

20.3.2

Change name

To change the name of the input or output group:

1. Overwrite the name
2. Select **OK**.
The new name is confirmed.

20.4

Detector sensitivity



Notice!

Detector sensitivity is automatically reset to the default setting when the entire panel, an individual detector, or a logical zone is reset or when the detector is replaced.

Two different sensitivities can be assigned to detectors and logical zones in the FSP-5000-RPS programming software – a default setting and an alternative setting.

It is possible to switch between the default and alternative setting on the panel controller.

To change the setting:

1. In the start menu, select **Configuration**
2. **Detector sensitivity**
Various lists are offered. Select one of the detector or logical zone lists that are offered.
A list of elements is displayed. Depending on the list you have selected, enter the number or the name of the element into the search screen.
3. Select the list field you require, e.g. a logical zone in this case.
Two settings are displayed: There is a checkmark in the selection field in front of the active setting.
4. Select the selection field of the detector sensitivity you require.
A checkmark is set in this field.
5. Select **OK** to confirm the selection or **Cancel** to cancel the operation.
The selected detector sensitivity is confirmed for the detector.

20.5

Operator

Depending on whether the same password is used per access level, or whether each user has a different password, one of the following two options is offered:

If the same password is used per access level:

- **Change universal password:** The same password can be configured for each access level in the FSP-5000-RPS programming software. This means that all operators with access authorization for the second level receive the same password, for example. The password for access levels two to four can be changed.

If each user uses a different password:

- **Change operator data:** Change the password for an operator.
- **Set default password:** Reset a user password to the following number sequence: 000000.

**Notice!**

The password must contain at least three digits.

20.5.1**Change password**

1. In the start menu, select **Configuration**
2. **Operator**
3. **Change operator data**
A list of all operators is displayed.
4. Select the list field you require.
5. Enter a new password. Repeat the new password in the bottom field again.
On the display, each digit of the password is indicated with an asterisk so that nobody else can see the password.
6. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The entry is confirmed.

20.5.2**Change universal password**

1. In the start menu, select **Configuration**
2. **Operator**
3. **Change universal password**
4. Depending on the access level for which the password is to be changed, select the list field you require.
5. Enter a new password and repeat the entry in the bottom field again.
On the display, each digit of the password is indicated with an asterisk so that nobody else can see the password.
6. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The entry is confirmed.

20.5.3**Set Default Password**

1. In the start menu, select **Configuration**
2. **Operator**
3. **Set default password**
A list of all operators is displayed.
4. Select the list field you require.
The list field is marked.
5. Select **Reset**.
The operator's password is reset to his/her previous password.

20.6 Rename elements

To change the name of an element:

1. In the start menu, select **Configuration**
2. **Rename elements**
A list of all elements is displayed.
3. Select the list field you require.
An entry screen is displayed.
4. Enter a new name.
5. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The event with the new name is displayed on the list.

20.7 Network services

20.7.1 Ethernet

You can modify and activate the network settings (IP settings, Ethernet redundancy) of panels and remote operating panels that are networked via an Ethernet connection under **Configuration - Network**. Further information can be found in *Networking via Ethernet*, page 30.

20.7.2 Change date/time

If starting the panel for the first time enter the current time and date. The setting of the correct date is a prerequisite for connecting the panel to the Fire System Explorer server. For details please see *Change Date / Time*, page 85.

20.7.3 Remote Services

For general information about Remote Services refer to *Remote Services*, page 63.

To configure Remote Services:

1. Connect the Secure Network Gateway for Remote Services with the panel and the internet access point.
2. Go to **Configuration - Network services - Ethernet - IP settings**:
 - Enter the IP of the panel.
 - Select the **Use Ethernet settings** box.
 - Refer to the chapter *IP settings*, page 30 for details.
3. Restart the panel:
 - Press once shortly on the power button to shut down the panel.
 - Wait until the shutdown is complete. Refer to *Switch on and switch off*, page 20.
 - Press once shortly on the power button to start the panel.
4. Go to **Configuration - Network services - Change date / time**:
 - Enter the current date.
 - Refer to the chapter *Change date/time*, page 83 for details.
5. Go to **Configuration - Network services - Remote Services - Remote ID**:
 - Enter the 10-digit Remote ID provided by Fire System Explorer using the alphanumeric keypad.
 - To delete the Remote ID, select **Clear**.
 - Confirm with **OK** to save and return to the **Network services**.
 - To exit without saving, select **Cancel**.
6. **System ID**:

- The Fire System Explorer assigns the System ID to the panel. Normally, there is no need to change it.
 - To change it, select **Change System ID**. and enter the new System ID using the alphanumeric keypad.
7. Confirm with **OK** to save and return to the **Remote Services** screen. To exit without saving, select **Cancel**.

**Notice!**

Only change the System ID if reusing an existing System ID.

20.8

Overview

To display important information on the valid configuration of the system:

1. In the start menu, select **Configuration**
2. **Overview**

The following information is displayed:

- Configuration and additional information on this
- **Date**
- Configuration version (**Config. version**)
- **Number**
- **Name**
- **IP address**
- **Scope**
- **Country**
- **Time zone**
- **Menu name**

21 Further functions

This chapter contains information about the following points:

- *Change Date / Time, page 85*
- *Master password, page 85*
- *Remote Services, page 86*
- *Change password, page 87*
- *Performing a fire drill, page 87*
- *Alarm counters, page 88*

21.1 Menu overview

Further functions	->	Change date / time	Master password
		Remote Services	Change password
		Drill	Alarm counters

21.2 Change Date / Time

To change the date and time:

1. In the start menu, select **Further functions**
2. **Change date / time**
3. Touch the field you require and enter a new value.
4. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The new values for date and time are accepted into the system.

21.3 Master password



Notice!

With the master password, all functions can be operated and passwords and names can be changed.

One of the following two options is offered:

- Entering a master password that is valid indefinitely. This password cannot be changed and is available from the relevant Bosch branch on request.
- Entering a master password that is valid for a specified period of time. This password is only valid for 24 hours. The panel controller can issue a number on request. This number must be forwarded to the Support department. The Support department can then issue a 24-hour password.

After the password has been entered, various options are offered.

21.3.1 Enter the master password that is valid indefinitely

1. In the start menu, select **Further functions**
2. **Master password**
3. Enter the master password.
4. Select **OK** to confirm the entry or **Cancel** to cancel the operation.
The master password is accepted and the operator is logged in.
The user passwords can now be changed:
Select Change password.
Additional options may be offered.

21.3.2 Enter the 24-hour master password

The following procedure must be followed in order to obtain a 24-hour master password: The panel controller generates a number on request. Please forward this number to the after sales support department by telephone or e-mail. A password which is only valid for 24 hours will be provided.

1. In the start menu, select **Further functions**
2. **Master password**
3. **Create number**
4. **Request password**
A number is displayed.
5. Give the number issued by the system to the Support department.
6. Once you have received the 24-hour password from the Support department, select **Enter password!**.
7. Enter the password.
The 24-hour master password is accepted and the user is logged on.

Change password

To change passwords, select **Change password**.
Additional options may be offered.

21.4 Remote Services

Remote Connect

In FSP-5000-RPS under **Remote Services** -> **Remote Connect** it is possible to select the **Auto Answer** feature. If **Auto Answer** is selected, the remote connection establishes automatically.

To establish a remote connection without the Auto Answer feature:

1. In the start menu, select **Further functions**.
2. Select **Remote Services**.
3. Select **Enable call**.
The **Enable call** button disappears.
The status changes from **Disabled** to **Inactive**.
When the connection is established, the status changes to **Active**.
4. To disconnect the connection, select **Stop Remote Connect**.
⇒ The original panel screen is displayed.



Notice!

If you open another menu while the remote connection is active, the message **Teleservice Active** is displayed.

To hide this message, touch the screen.

The message will be displayed every 30 seconds while the remote connection is active.

Remote Maintenance

To stop data transmission for Remote Maintenance:

1. In the start menu, select **Further functions**.
2. Select **Remote Services**.
3. Select **Block**.
Data transmission to the Fire System Explorer stops until the next restart of the panel controller.
4. To allow Remote Maintenance again, select **Unblock**.



Notice!

Blocking or unblocking Remote Maintenance affects all panels in the network. You cannot block or unblock this service for a single panel.

Remote Alert

To stop data transmission for Remote Alert messages:

1. In the start menu, select **Further functions**.
2. Select Remote Services.
3. Select **Block**
4. Transmission of messages to the Fire System Explorer stops until the panel controller is restarted.
5. To allow Remote Alert again, select **Unblock**.



Notice!

Blocking or unblocking Remote Alert affects all panels in the network. You cannot block or unblock this service for a single panel.

21.5 Change password



Notice!

If all operators with the same access authorization have the same password, this function cannot be used.

1. In the start menu, select **Further functions**
2. **Change password**
A list of all operators is displayed.
3. Select the list field you require.
4. Enter the password.
On the display, each digit of the password is indicated with an asterisk so that nobody else can see the password.
5. Enter a new password and repeat the entry in the bottom field again.
6. Select **OK** to confirm the entry or **Cancel** to cancel the operation.

21.6 Performing a fire drill



Caution!

Risk of miscommunication

If a genuine alarm occurs during a fire drill, the drill is abandoned. The drill can only be restarted once the alarm is cleared.

During a drill, all signaling devices are activated.

To start a drill:

1. In the start menu, select **Further functions**
2. **Drill**
3. Confirm **Start drill** with **OK**
The drill is started.

To end the drill, select **Stop drill**.

During the fire drill, fire alarms, fault messages and supervisory alarms are displayed.

To switch between the fire drill display and the message display in question, select **Return to message screen** or **Return to drill screen** on the status bar.

If an alarm or a fault/supervisory alarm is sounded during a fire drill, the panel controller reacts as described in the table below:

	Fire alarm	Fault/ supervisory alarm
The drill signaling devices are switched off.	Yes	No
The drill is automatically terminated.	Yes	No
Display switches to	Alarm indication	Fault indication
Fire drill after event ends	Must be restarted manually	Continue

A new function cannot be selected until the fault/supervisory alarm and/or the fire drill have been completed.

21.7

Alarm counters

Show lifetime event counters

During the lifetime of the panel, the following alarm conditions and messages are counted locally for each panel (**Local**) and in scope for all panels within the complete network or a network group, depending on the configuration (**Scope**):

- External alarm: all fire alarm conditions which triggered an external device
- Internal alarm: all fire alarm conditions which did not trigger an external device (e.g. if the alarm occurred in daymode)
- Maintenance alarm: all alarm messages from detectors in walktest mode.

To display the number of alarm conditions and messages which have been counted so far:

1. In the start menu, select **Further functions**
2. **Alarm counters**

The figure after the message type shows the number of conditions and messages counted so far for the individual panel (**Local**) and summed up for all panels in the complete network or a network group, depending on the configuration (**Scope**).



Notice!

The scope of the counters depends on the configuration of **Scope** of the node in the FSP-5000-RPS programming software. If **Group** is set, conditions and alarms of all panels within a particular network group, depending on the logical node address, are counted. If **Network** is set, all conditions and alarms of all panels within the complete network are counted.

Reset counters

You can reset the alarm counter for individual alarm types to 0.

To reset alarm counters

1. In the start menu, select **Further functions**
2. **Alarm counters**
3. Mark the alarm counter you require (e.g. external alarm)
4. Select **Reset**
5. Confirm the message **Attention: Counter will be reset** with **OK** to reset the alarm counter to 0 or select **Cancel** to cancel the operation.

6. Reboot the panel to display the reset values.



Notice!

In order to reset alarm counters, you need authorization level 4.

22 Reset

This chapter contains information on how to reset elements.

During resetting, the selected elements are reset to the initial state.

- **Event type:** Display a list of all message types. The message types can be reset for the entire **Scope**.
- **Scope:** Depending on the **Scope** set in FSP-5000-RPS, the current panel, all panels in a group or all the panels in the entire network are reset.
- **Logical zone**
- **Detector**
- **This panel:** All elements of the panel that are not in standby mode are reset



Notice!

If the **Scope** refers to one panel, the list fields **This panel** and **Scope** have the same function.

22.1 Menu overview

Reset	->	Event type	Scope
		Logical zone	Detector
			This panel

22.2 Resetting elements

To reset a detector or logical zone, for example:

1. In the start menu, select **Reset**
2. Select the element you require.
3. Select the detector or zone.
4. Select the required list fields.
The list fields are marked.
A list of the detectors or zones is displayed.
5. Select **Reset**.
The selected elements are reset.



Notice!

As long as the elements are still in the process of resetting, no other entries can be made.

If a list field is marked with an R, the process of resetting is not yet complete for this element:

TEXT	R
------	---

If an element cannot be reset, it will continue to be displayed in the list.

After the elements have been reset, the standby display is displayed.

To reset a manual call point, use the reset key or replace the glass window.

To reset an automatic detector: If there is still smoke in the detection chamber please ventilate.

23 Control / Monitor

This chapter contains information about the following topics:

- *Activate doorholder, control element or HVAC, page 91*
- *Go to element, page 91*
- *Search for function, page 92*

23.1 Menu overview

Control Monitoring	->	Activate doorholder	Activate HVAC
		Activate control element	Search function
		Go to element	

23.2 Activate doorholder, control element or HVAC

You can manually activate doorholders, control elements or climate systems.

1. Press **Control Monitoring**
2. Press the required button (**Activate doorholder**, **Activate control element** or **Activate HVAC**) to open a list with all available elements of the required group.



Notice!

The individual control of each group is only possible for panel controllers with a premium license.

Press the required element to start or stop the activation of this element immediately. Press **All On** to activate all elements or **All Off** to stop the activation of all elements at a time. Use \checkmark and \wedge to scroll through the list. The element entries change their background color according to their current state.

The background colors of the elements have the following meaning:

- Red: Elements which are actively being controlled in case of an alarm
- Fuchsia: Elements which are actively being controlled without a real alarm
- Green: Elements which are not active
- Yellow: Elements in fault or disabled, no control is possible.

23.3 Go to element

To search for an element which is connected to the system:

1. In the start menu, select **Search function / element**
2. **Go to element**
Three different lists are offered.
3. Select a list, e.g. **By description**.
A list of the detectors is displayed.
4. Select the list field you require.
Different selection fields may be offered for the selected element (e.g. **OK**, **Bypass**).
What is displayed depends on:
 - the message types (e.g. fault, alarm etc.) that can be assigned to this element.
 - the mode (e.g. bypassed, reset etc.) that the selected element is in.

23.4 Search for function

To search for a:

1. In the start menu, select **Control Monitoring**
2. **Search function**
A list of all functions is displayed.
3. Select the list field you require.
The submenu of the selected function is displayed.

24 Boot menu

To enter the boot menu of a running panel:

1. Press the power button shortly to shut down the panel.
Wait until the panel has shut down completely.
2. Press the power button shortly to start the panel.
3. Put your finger at once somewhere on the touch screen and leave it there until the boot menu opens.



Notice!

The functions that can be executed via the boot menu are intended for trained experts only.

In the boot menu you find the following functions:

- Start: Continue the boot process and exit the menu.
- Start with Default Configuration: Press to start the panel with a hardcoded default configuration.
- Reset to Factory Settings: This function is currently not implemented.
- Calibrate Touchscreen: To calibrate the touchscreen press the button and follow the instructions on the screen. If the touchscreen is totally decalibrated and touching the button does not work, touch the screen at any position for at least 4 seconds and then release. Releasing also starts the calibration process.
- Update Firmware: Update the panel firmware via a file on a SD card. Copy the SWU file provided via the Extranet to an SD card and enter it into the SD card slot. Then press Update Firmware.



Notice!

Please make sure that there is only one SWU file available on the card. To make the new firmware become effective, press the Toggle Firmware and Reboot button.

-
- Toggle Firmware and Reboot: Press to use the firmware that was uploaded via the SD card. If this is already in use, you can also use this function to switch back to the previous firmware version of the panel.

Index

Symbols

"Double arrow" function key	14
"Enter" function key	14
"Left arrow" function key	14
"Log in" function key	14
"Right arrow" function key	14

A

Access authorization	22, 23
Activate Outputs	67
Activate signaling devices	43
Activate Transmission Device	68
Alarm Counters	88
Alarm delay	36
Alarm message	38
Alarm message, information	39
Alarm message, sequence	39
Alarm verification	37, 44
Alarm, displaying further information	41
Alarm, individual detector	40
Alarm, logical zones	39
Alarm, message number	40
Assigning tested elements to a walktest group	72
AVENAR keypad, display	33
AVENAR keypad, operation	33

B

Blocking an element	51
Boot menu	93
by description	24
by number	24
by Number (no Description shown)	24
Bypassing detectors	46
Bypassing elements	52
Bypassing/Un-bypassing buzzer	54, 68

C

Calibrate touchscreen	93
Calling up the start menu	9, 23
CAN-Bus	61
Change Date / Time	85
Change operator data	82
Change password	82, 87
Change universal password	82
Changing entry	28
Changing language display	9, 28, 67
Changing time for resetting to night mode	77
Checking access authorization	23
Configuration version	84
Consistency check	62, 63

Country	84
---------	----

D

Day mode	38, 76
Day/night mode, showing details	77
Day/night mode, switching	76
Default language	67
Deleting numbers	28
Description, search by	26
Detector sensitivity	81
Diagnostics	58
Diagnostics, All info for one element	58
Diagnostics, element details	58
Diagnostics, Info for all elements	58
Diagnostics, Info for element group	58
Diagnostics, modules	59
Display Test	59
Displaying bypassed element groups	52
Dual-detector dependency	37
Dual-zone dependency	37

E

Ending the walktest	72
Enter Password	22
Enter the 24-hour master password	86
Enter the master password that is valid indefinitely	85

Entering numbers	27
Entering text	27
Ethernet	30
Ethernet configuration	30
Ethernet ports	63
Ethernet redundancy	31

F

Fault message	47
Fault message, acknowledging	47
Fault message, further information	49
Fault message, information about element group	48
Fault message, information about elements	49
Fault message, latest message	48
Fault message, resetting	50
Fault message, sequence	48
Fault, signals	50
Fire	36
Fire alarm, acknowledging message	43
Fire alarm, signaling	42
Firmware version	61
Fixed keys	13
Function keys	13

G			
Group setting	79	Physical node number	62
H			
Hardware version	61	Ping command	63
Heat	36	Power button	20
History log, changing filter	74	Production Date	61
History log, combining filters	74	Q	
History log, event numbers	75	Quick entry of text and numbers	28
History log, filter	73	R	
History log, printing out data	74	Rename elements	83
History log, setting filter	73	Reset counters	88
History log, status bar functions	74	Resetting alarm message	45
I		Resetting external signaling devices	43
Input group, adding elements	79	Resetting, detectors	90
Input group, deleting elements	79	Resetting, elements	90
Input/output group, changing name	81	Resetting, message type	90
Interfaces	62	Resetting, scope	90
Intermediate alarm storage	37	Resetting, this panel	90
IP Address	84	Resetting, zone	90
IP settings	30	Routing table	62
L		RSN	21
LED Test	59	RSTP settings	31
LED Test on modules	61	S	
List fields, states	25	Safe state	21
List, assigning mode	26	Scope	84
Lists	24	Search Function/Element	26
Lists, scrolling	25	Search mask	26
Logging in	22	Searching, device description	92
Logging off	22	Searching, element	91
Logical addressing	29	Searching, function	92
M		Selecting the menu	23
MAC Address	61	Set Default Password	82
Master password	85	Show lifetime event counters	88
Material number	61	Silence internal buzzer	43
N		Silence signaling devices on	43
Network	62	Smoke	36
Night mode	37, 76	Standby display	18, 29
Number, search by	27	Starting the walktest	71
O		Starting time to investigate	44
Operator	81	Status bar	18
Optical/acoustic signals	38	Supervisory alarm	36
Overview	84	Support information, support service, address	19
P		Switch off	20
Panel Passport	61	Switch on	20
Password, default setting	22	Switching status bars	29
Performing a fire drill	87	T	
Physical addressing	29	Time to acknowledge	44
Physical node address (RSN)	79	Time to investigate	44
		Time zone	84
		Touch screen	17

Triggering fire verification	44
Types of alarm	36
U	
Unblocking elements	56
Un-bypassing bypassed element groups	52
Un-bypassing elements	52
V	
Voice Alarm System	
Plena	65
VAS over IP	65
W	
Walktest Group	80
Walktest groups	69
Walktest groups, adding elements	69
Walktest groups, deleting elements	69
Walktest, displaying tested elements	72
Walktest, displaying untested elements	72
Water	36

Bosch Sicherheitssysteme GmbH

Robert-Bosch-Platz 1

70839 Gerlingen

Germany

www.boschsecurity.com

© Bosch Sicherheitssysteme GmbH, 2025

Building solutions for a better life

202503271249