Universal Transmitter

Overview

The ISW-EN1210 is a universal transmitter.

Figure 1: Transmitter Components



- 1 Frequency Band pins
- 2 RESET button
- 3 Circuit board tab
- 4 Antenna
- 5 Housing release tab
- 6 Battery
- 7 Tamper switch with spring
- 8 N/O–N/C pins
- 9 Input terminal

1.0 Installation and Setup

1.1 Install the Mounting Bracket

- 1. Pry the top lip (refer to *Figure 2*) of the mounting bracket up, and lift the bracket off the transmitter.
- 2. Mount the bracket on the wall. Install two of the supplied screws in the mounting screw holes.

The third mounting screw, installed under the battery, is optional. Refer to Section.1.5 Install the Battery.

Figure 2: Mounting Bracket



- 1 Top lip
- 2 Mounting screw holes (mounting bracket)
- 3 Bottom catch
- 4 Mounting screw hole (housing base, under the battery)

1.2 Open the Housing

- 1. Use a small flat-blade screwdriver to press the housing release tab (refer to *Figure 1*) on the bottom of the transmitter.
- 2. Separate the housing cover from the housing base. Refer to *Figure 3*.



1.3 Mount the Transmitter on the Bracket

Clip the transmitter housing onto the bracket:

- 1. Hook the housing base onto the bottom catch (refer to *Figure 2*).
- 2. Press the top of the housing base into place under the top lip of the bracket.

1.4 Configure the Transmitter

1.4.1 Select the Frequency Band

- 1. Select the appropriate frequency band for your geographic area.
- 2. Place a jumper on the appropriate Frequency Band pins (refer to *Figure 4*).

Figure 4: Frequency Band Settings



- 1 North America (902 MHz to 928 MHz) (**default**)
- 2 Australia (915 MHz to 928 MHz)
- 3 New Zealand (921 MHz to 928 MHz)



1.4.2 Select the Input Type

The N/O-N/C pins allow the choice of a normally open or normally closed state for the contact circuit wired to the input terminal.

The transmitter is shipped set for normally closed, with no jumper on the N/O selection pins.

If you change the transmitter's input setting after initial installation, press the RESET button for the new setting to be effective. Do not touch the Frequency Band pins.

• To select normally open (N/O), place a jumper on the pins,

or

• To select normally closed (N/C), remove the jumper from the pins.

1.5 Install the Battery

- You can secure the transmitter with a third mounting screw located under the battery (*Figure 2*).
- Accessing this mounting screw on an active transmitter requires opening the housing and removing the circuit board (refer to *Section 2.0 Remove the Circuit Board*).
- 1. Install the new battery.
- 2. Press the RESET button. Refer to *Figure 1*.

1.6 Register the Transmitter

You must register the transmitter with the system in order for the transmitter to be monitored and supervised. When the transmitter is supervised, it sends a check-in message to the serial receiver or network coordinator every 3 min. Each transmitter has a unique factory-programmed identification number.

Refer to the receiver's documentation for details on registering a transmitter.

1. When prompted by the receiver to reset the transmitter, press the RESET button on the transmitter.

i

When pressing the RESET button, do not touch the Frequency Band pins. Touching the Frequency Band pins while pressing the RESET button can inadvertently set the transmitter to the wrong frequency band.

©2009 Bosch Security Systems, Inc. 130 Perinton Pkwy, Fairport, NY 14450 USA (800)289-0096 F01U0127337-01 | 3/09



- 2. Replace the housing cover on the mounted housing base.
- 3. Test the transmitter by activating each of the conditions and ensuring an appropriate response.

2.0 Remove the Circuit Board

- 1. Remove the transmitter cover. Refer to Section 1.2 Open the Housing.
- 2. Insert a small flat-blade screwdriver between the edge of the circuit board and the edge of the housing near the circuit board tab (refer to *Figure 1*).
- 3. Press the handle of the screwdriver downward, lifting the circuit board on one side.
- 4. Remove the circuit board from the housing.

To install the circuit board, place the edge of the circuit board under the circuit board tab and snap the other side of the circuit board into place.

3.0 Replace the Battery

- 1. To remove the transmitter from the mounting bracket, pry the top lip of the mounting bracket up and lift the transmitter from the bracket.
- 2. Remove the housing cover from the housing base. Refer to Section 1.2 Open the Housing.
- 3. If the transmitter is installed with three mounting screws, remove the circuit board from the housing base. Refer to *Section 2.0 Remove the Circuit Board*.

If the transmitter is installed with only two mounting screws, removal of the circuit board is not necessary.

4. To replace the battery, use a small screwdriver to push the old battery out of the battery holder.



Removing the battery causes a tamper condition.

- 5. Install a new battery.
- 6. Press the RESET button to initialize the transmitter. Refer to *Figure 1*.

4.0 Specifications

External contacts	Normally open (N/O) or normally closed (N/C)
Distance, external contact to ISW-EN1210	6.1 m (20 ft) maximum
Typical Battery Life	3 to 5 years
Battery type	Panasonic [®] CR123A or equivalent
Operating Temperature	-20° to +60°C (-4° to +140°F)
Relative humidity	Up to 90% (non-condensing)

Trademark

 $\mathsf{Panasonic}^{\textcircled{\text{(B)}}}$ is a registered trademark of Matsushita Electric Industrial Co., Ltd.