# DCNM-D | Single participant

**BOSCH**

1 - How to adjust the volume:

Adjust the headphone volume by scrolling the volume wheel on the side your headphone is plugged.

2 - What buttons to press:

Press to issue or cancel micropohone request.

Press to temporary mute the micropohone.

GREEN LED:
Indicates that a request-to-speak is accepted.
Flashing indicates first in list.
You cannot speak until red light.

RED LED:
Indicates that the microphone is active you can push the microphone button to disable.
Flashing indicates last minute.

WHITE LED:
White speaker icon indicates that the floor is granted when the button is pressed.