

BVMS Lite 10.1



BVMS Lite is a unique IP video security solution that provides seamless management of digital video, audio, and data across any IP network. It provides the best video management system to go with Bosch video surveillance devices, leveraging the unique capabilities of Bosch cameras and recording solutions. It nevertheless offers interfaces and standards to integrate other systems and manufacturers.

The software is provided as an e-license via e-mail.

Certifications and approvals

General Data Protection Regulation

The General Data Protection Regulation (GDPR) is enforced on the 25th of May 2018. As a regulation it will be directly applicable to all EU member states without the need for national implementing legislation. As information captured, processed and stored by video surveillance systems is classified as "sensitive" the GDPR will cause significant impact on the video surveillance installations throughout Europe.

BVMS includes the required functionality to ensure an organization can be GDPR compliant.

- ▶ Embedded resilience - keep operations up and running even when multiple system components fail.
- ▶ Bosch video at its best - the best user-experience combining Bosch cameras with BVMS.
- ▶ Integration - integrate third-party cameras, storage and further systems into BVMS .
- ▶ IT environments and data security - benefit from full IT compatibility from installation to day-to-day management in a secure way.
- ▶ Free of charge up to 8 cameras - load the license, and off you go.

Installation/configuration notes

The BVMS system design guide is published on the following website:

 [Bosch Building Technologies Knowledge Base.](#)

The system design guide summarizes the BVMS design details, and serves as a guide to planning a BVMS system with Bosch cameras and storage. It focuses on BVMS combined with the VRM.

To get started, read the following article on the Bosch Security & Safety community website:

 [BVMS - Quick start overview](#)

BVMS Enterprise

Multiple BVMS Lite, Plus, Professional or DIVAR IP systems can be combined into one BVMS Enterprise System.

Cameras within system context	200000
Cameras per operator	10000

Sub-systems	Between 10 sub-systems with 1000 cameras per system or 100 sub-systems with 100 cameras per system.
-------------	-----------------------------------------------------------------------------------------------------

Software assurance

The complexity of security systems has increased significantly over the last couple of years. At the same time, you are still relying on your system to mitigate security risks. With Bosch Software Assurance, you can relax knowing you can always approach us for help to ensure your system keeps on running. You can find the terms and conditions of Bosch Software Assurance on the following website:



[About Bosch Software Assurance](#)

Technical specifications

The release notes give a detailed overview on the changes that are implemented, compared to the previous BVMS version.

The architects and engineering specifications specify in detail what the system is capable of.

Both documents can be found on the following web page:



[Bosch Building Technologies Knowledge Base](#)

System limits



Notice

The system limits are based on the hardware recommendations.

Maximum number of workstations	5
Maximum number of cameras	42
Maximum number of intrusion panels	5
Maximum number of DVRs	10
Maximum number of VRMs	2
Maximum number of sustained events (logbook) / sec	500
Maximum number of sustained events (without logbook) / sec	2500

Maximum peak event load / sec (within 60 minutes)	5000
Maximum number of events / sec from ONVIF cameras	500
Logbook size	4GB



Notice

The logbook size can be increased by upgrading the Microsoft SQL Server Express edition included in the BVMS installation package.

Languages

Component	Languages
Quick installation guide	English, French, German, Simplified Chinese and Spanish
Configuration manual	English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Czech, Greek, Polish, Swedish, Turkish and Korean.
Operation manual	English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Czech, Greek, Polish, Swedish, Turkish and Korean.
Software	English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Hungarian, Japanese, Czech, Danish, Finnish, Greek, Norwegian, Polish, Swedish, Thai, Turkish, Korean, Arabic, and Vietnamese

Hardware recommendations

Cameras

All Bosch cameras can be used under the device compatibility concept, which you can find on the Bosch Security and Safety Community in the following article:



[How-to: BVMS - Device compatibility](#)

BVMS is an ONVIF Profile S certified video management system.

Management Server, Video Streaming Gateway, Video Recording Manager, and Mobile Video Service

It is recommended to run the Video Recording Manager and the BVMS Management Server on the same computer.

The recommended specifications for BVMS Lite are based on the Bosch DIVAR IP AiO 5000.

Item	Description
Operating System	Windows Server 2012 R2 (64-bit) Windows Server 2016 (64-bit) Windows 10 Professional (64-bit) build 1909 Windows 10 Professional (64-bit) build 2004 Windows 10 Enterprise (64-bit) 2019 LTSC build 1809 Windows Server 2019 (64-bit)
CPU	Intel i3-8100
RAM	8GB
Free disk space	15GB (+ 15% of the hard-drive after installation)
Network	1 Gigabit/s network interface card

Operator Client

Item	Description
Operating System	Windows 10 Professional (64-bit) build 1909 Windows 10 Professional (64-bit) build 2004 Windows 10 Enterprise (64-bit) 2019 LTSC build 1809
CPU	Intel Core i7-8700 (3.2 GHz)
RAM	8GB
Free disk space	Minimum 5GB for Single Site Systems Minimum 10GB for Enterprise Systems

Item	Description
Network	1 Gigabit/s network interface card
Display resolution	Minimum: 1280 x 1024 Maximum: 3840 x 2160
Graphic card	Nvidia Quadro P620 Nvidia Quadro P2000 Nvidia Quadro P4000 Nvidia Quadro RTX4000 Nvidia Quadro P2200 Intel HD Graphics 630

Network

To achieve the performance listed in the table below, a 1 Gigabit/s network is a minimum requirement between the Operator Client and Management Server.

(Unicast) Maximum number of workstations simultaneously viewing the same camera	5
(Multicast) Maximum number of workstations simultaneously viewing the same camera	100
Event response time (assuming sufficient network performance considering bandwidth and delay)	< 1 second
Alarm visibility time (assuming sufficient network performance considering bandwidth and delay), including 1 live image pane, 1 instant playback image page, and 1 map image pane.	< 2 seconds

(i) Notice
When the system does not have enough network resources, or is experiencing a temporary decrease in network performance, the event response time and alarm visibility time may increase.

(i) Notice
The list of communication channels and required network ports can be found in the BVMS Configuration manual.

Storage devices

The storage quick selection guide, which also includes non-Bosch storage devices, can be found on:

<http://www.boschsecurity.com/bvms>

Device	Series
Bosch DIVAR IP	2000, 3000, 5000, 6000, 7000
Bosch DIVAR IP AiO	5000, 7000
Bosch DSA E-Series	2300, 2400, 2500, 2600, 2700, 2800
Bosch DIVAR AN	3000, 5000
Bosch DIVAR network	2000, 3000, 5000
Bosch DIVAR hybrid	3000, 5000
Bosch DVR	700, 4xx, 6xx
Bosch DiBos	Firmware 8.7
Bosch Recording Station (BRS)	Firmware 8.10 / 8.11

Other hardware

Type	Device	Remarks
Decoder	Bosch VIDEOJET decoder 3000	n/a
Decoder	Bosch VIDEOJET decoder 7000	n/a
Decoder	Bosch VIDEOJET decoder 8000	Supports displaying of 4K cameras
Foyer card reader	MINITER 485	n/a
Serial input	Werner Electronic DTP3N	n/a
Intrusion panel	Bosch G-series B9512G 3.03.14, Bosch B5812G 3.03.14, Bosch B5512 3.03.14, Bosch B4512 3.03.14, Bosch B3512 3.03.14, Bosch B6512 3.03.14	Automation Device in the intrusion panels must be configured as Mode 2

Type	Device	Remarks
Intrusion panel	Bosch D9412GV4 2.03.018, Bosch D7412GV4 2.03.018	Microsoft Windows Patch 3155464 should not be installed
Monitor wall	Barco Transform N series	RCPPPlus agent 0.9.5.0
Analog matrix switch	Bosch Allegiant Series	Firmware 8.75 or later, Master control software 2.94
ATM/POS Bridge	Bosch ATM/POS Bridge	Version 1.10.00.12
Keyboard	Bosch KBD-Universal XF	USB
Keyboard	Bosch Intuikey	Serial, firmware 1.96
Digital I/O	Advantech ADAM-6050, Advantech ADAM-6052, Advantech ADAM-6060, Advantech ADAM-6066	n/a
USB to serial	Belkin serial adapter F5U103VEA	n/a
Ethernet to serial	Control DeviceMaster RTS 4-port	n/a
LPR camera	Tattile Vega Basic Tattile Vega Smart Tattile Vega1	n/a

Ordering information**MBV-BLIT-101 License Lite base**

Includes 8 camera/decoder expansions, 2 workstation expansions, 8 failover recording channels, 8 dual-recording channels, 2 keyboard expansions, 1 DVR, and ATM/POS, allegiant and OPC functionality.

Order number **MBV-BLIT-101 | F.01U.389.465**

MBV-XCHANLIT-101 License Camera/decoder expansion

Expansion license for 1 encoder/decoder channel. Order the exact number required.

Order number **MBV-XCHANLIT-101 | F.01U.389.467**

MBV-XDVRLIT-101 License DVR expansion

Expansion license for 1 DVR. Order the exact number required.

Order number **MBV-XDVRLIT-101 | F.01U.389.466**

MBV-XDURLIT-101 License Camera dual recording expansion

Expansion license for 1 encoder channel used for dual recording. Order the exact number required.

Order number **MBV-XDURLIT-101 | F.01U.389.468**

MBV-XFOVLIT-101 License VRM Failover channel expansion

Expansion license for 1 encoder channel used with a Failover VRM. Order the exact number required.

Order number **MBV-XFOVLIT-101 | F.01U.389.469**

MBV-XINTLIT-101 License Intrusion panel expansion

Expansion license to integrate intrusion panels.

Order number **MBV-XINTLIT-101 | F.01U.389.470**

MBV-XKBDLIT-101 License Keyboard expansion

Expansion license for 1 CCTV keyboard. Order the exact number required.

Order number **MBV-XKBDLIT-101 | F.01U.389.471**

MBV-XLPRIT-101 License LPR camera expansion

Expansion license for 1 (Tattile) LPR camera. Order the exact number required.

Order number **MBV-XLPRIT-101 | F.01U.389.475**

MBV-XPILIT-101 License Person ident. channel expansion

Expansion license for 1 Person Identification channel. Order the exact number required.

Order number **MBV-XPILIT-101 | F.01U.389.473**

MBV-XWSTLIT-101 License Workstation expansion

Expansion license for 1 workstation (each extra workstation requires 1 license).

Order number **MBV-XWSTLIT-101 | F.01U.389.472**

Software Options**MBV-MCHANLIT License for MBV-XCHANLIT-*, 1yr**

One year of maintenance cover for the BVMS Lite camera/decoder channel expansion license.

Order number **MBV-MCHANLIT | F.01U.362.469**

MBV-MDVRLIT License for MBV-XDVRLIT-*, 1yr

One year of maintenance cover for the BVMS Lite DVR expansion license.

Order number **MBV-MDVRLIT | F.01U.362.467**

MBV-MLIT License for MBV-BLIT-*, 1yr

One year of maintenance cover for the BVMS Lite base license.

Order number **MBV-MLIT | F.01U.362.465**

MBV-MDURLIT License for MBV-XDURLIT-*, 1yr

One year of maintenance cover for a BVMS Lite Dual Recording VRM expansion license.

Order number **MBV-MDURLIT | F.01U.377.531**

MBV-MFOVLIT License for MBV-XFOVLIT-*, 1yr

One year of maintenance cover for a BVMS Lite Failover VRM expansion license.

Order number **MBV-MFOVLIT | F.01U.377.533**

MBV-MINTLIT License for MBV-XINTLIT-*, 1yr

One year of maintenance cover for a BVMS Lite intrusion panel expansion license.

Order number **MBV-MINTLIT | F.01U.377.535**

MBV-MKBDLIT License for MBV-XKBDLIT-*, 1yr

One year of maintenance cover for a BVMS Lite CCTV keyboard expansion license.

Order number **MBV-MKBDLIT | F.01U.377.537**

MBV-MWSTLIT License for MBV-XWSTLIT-*, 1yr

One year of maintenance cover for a BVMS Lite Workstation expansion license.

Order number **MBV-MWSTLIT | F.01U.377.539**

MBV-MPILIT License for MBV-XPILIT-*, 1yr

One year of maintenance cover for a BVMS Lite person identification channel expansion license.

Order number **MBV-MPILIT | F.01U.377.555**

MBV-MLPRIT License for MBV-XLPRIT-*, 1yr

1 year of maintenance cover for the (Tattile) LPR camera expansion license.

Order number **MBV-MLPRIT | F.01U.389.476**

Represented by:

Europe, Middle East, Africa:
Bosch Security Systems B.V.
P.O. Box 80002
5600 JB Eindhoven, The Netherlands
Phone: + 31 40 2577 284
emea.securitysystems@bosch.com
emea.boschsecurity.com

Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Ring 5
85630 Grasbrunn
Germany
www.boschsecurity.com

North America:
Bosch Security Systems, LLC
130 Perinton Parkway
Fairport, New York, 14450, USA
Phone: +1 800 289 0096
Fax: +1 585 223 9180
onlinehelp@us.bosch.com
www.boschsecurity.us

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
apr.securitysystems@bosch.com
www.boschsecurity.asia