






1 - How to adjust the volume:




Adjust the headphone volume by scrolling the volume wheel on the side your headphone is plugged.

2 - What buttons to press:




 Press and hold to mute the microphones of all participants.

 Press to activate the microphone.




GREEN LED:

Indicates that a request-to-speak is accepted.
Flashing indicates first in list.
You cannot speak until red light.



RED LED:

Indicates that the microphone is active you can push the microphone button to disable.
Flashing indicates last minute.



WHITE LED:

White speaker icon indicates that the floor is granted when the button is pressed.