
DCN-SWAT Conference Software Attendance & Access

www.boschsecurity.com





- ► Attendance Registration using ID-card with or without PIN-code, or present button
- ► Access Control using ID-card with or without PIN-code or PIN-code only
- ▶ All data instantly available to operator
- ▶ Print function to reproduce data

The Attendance Registration & Access Control software module is used to register attendance of delegates in a conference meeting, and to control access to the conference facilities in the conference room.

Functions

The functionality of Attendance Registration & Access Control software falls into two categories:

Attendance Registration:

It is possible to specify entrance requirements that delegates have to meet before entering the meeting. This normally means delegates have to insert an ID-card in a card reader, either at the entrance to the meeting or at the conference unit. Registration at a conference unit can also be done by pressing the 'Present' button.

It is possible to display lists on-screen of all 'present' and 'absent' delegates, and print hard copies.

Access Control:

The settings specified for Attendance Registration can be used for access control. This means that although delegates can enter the meeting, they cannot use any of the conference unit's facilities (such as microphone and voting) without access requirements. Access is controlled by means of ID- cards, with or without PIN-code (free seating). There is an option whereby delegates register attendance at the entrance using an ID-card reader, and a specific conference unit is than made available for them (fixed seating). Access control can be done on the conference unit only by ID-card with or without PIN-code or PIN-code only (fixed seating).

Ordering information

DCN-SWAT Conference Software Attendance & Access

Used for registering and accessing facilities in the conference room. Can only be used in combination with DCN-SW and DCN-SWDB software modules. Can not be used with the DCN Wireless Discussion System (DCN-WCCU).

Order number DCN-SWAT

DCN-SWAT-E Conference Software Attendance & Access E-code

Used for registering and accessing facilities in the conference room. Can only be used in combination with DCN-SW and DCN-SWDB software modules. Can not be used with the DCN Wireless Discussion System (DCN-WCCU). Electronic authorization code. Order number DCN-SWAT-E

DCN-SW Conference Software Main Module

A platform on which all other Conference software modules run.

Order number DCN-SW

DCN-SW-E Conference Software Main Module E-code

A platform on which all other Conference software modules run. Electronic authorization code. Order number DCN-SW-E

DCN-SWDB Conference Software Delegate Database

Can only be used in combination with DCN-SW. Order number DCN-SWDB

DCN-SWDB-E Conference Software Delegate Database

Can only be used in combination with DCN-SW. Electronic authorization code. Order number DCN-SWDB-E

Represented by:

Americas:

Bosch Security Systems, Inc. 12000 Portland Avenue South Burnsville MN 55337, USA Phone: +1-800-392-3497 Fax: +1-800-955-6831 audiosupport@us.bosch.com www.boschsecurity.com

Europe, Middle East, Africa:

Bosch Security Systems B.V. P.O. Box 80002 5617 BA Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

Asia-Pacific:

Robert Bosch (SEA) Pte Ltd, Security 11 Bishan Street 21 Singapore 573943 Phone: +65 6571 2808 Fax: +65 6571 2699 apr.securitysystems@bosch.com www.boschsecurity.asia

China:

Bosch (Shanghai) Security Systems Ltd. 201 Building, No. 333 Fuquan Road North IBP Changning District, Shanghai 200335 China Phone +86 21 22181111 Fax: +86 21 22182398 www.boschsecurity.com.cn

America Latina:

Robert Bosch Ltda Security Systems Division Via Anhanguera, Km 98 CFP 13065-900 Campinas, Sao Paulo, Brazil Phone: +55 19 2103 2860 Fax: +55 19 2103 2862 al.securitysystems@bosch.com www.boschsecurity.com