

# GV3 and GV4 Series Control Panels ROM Keys

---

## User Guide

### ROM Key compatible control panels:

#### BLUE KEY

---

- D9412GV4
- D7412GV4
- D7212GV4

#### GREEN KEY

---

- D9412GV3
- D7412GV3
- D7212GV3

### Update Instructions

Use a GV3 or GV4 ROM Key to update a GV3 or GV4 control panel's firmware. Look at the ROM key label to ensure you use the correct key for your control panel. For instructions on how to update a control panel, refer to the instructions printed on the back of the control panel's metal cover.

### Release Notes

To ensure compatibility with your system, review the Release Notes for this control panel version prior to using the ROM key. To read the latest control panel release notes, go to [www.boschsecurity.us](http://www.boschsecurity.us) and search for the keyword "GV3" or "GV4" on the **Online Catalogs > Intrusion Alarm Systems** page.

### Technical Support

If you have questions about the firmware update process, contact Bosch Technical Support at 800-289-0096.

---



**BOSCH**

